8901 Wisconsin Avenue Bethesda, MD 20889-5607

NMRI 95-76

December 1995



EVALUATION OF PORTABLE CARBON DIOXIDE ANALYZERS FOR USE AT 1-ATA ON U. S. NAVY SUBMARINES

R. S. Lillo A. Ruby W. R. Porter J. M. Caldwell

DIIC QUALITY DISFECTED 4

Naval Medical Research and Development Command Bethesda, Maryland 20889-5606

Department of the Navy Naval Medical Command Washington, DC 20372-5210

Approved for public release; distribution is unlimited

19960213 009

NOTICES

The opinions and assertions contained herein are the private ones of the writer and are not to be construed as official or reflecting the views of the naval service at large.

When U. S. Government drawings, specifications, or other data are used for any purpose other than a definitely related Government procurement operation, the Government thereby incurs no responsibility nor any obligation whatsoever, and the fact that the Government may have formulated, furnished or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise, as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

Please do not request copies of this report from the Naval Medical Research Institute. Additional copies may be purchased from:

Office of the Under Secretary of Defense (Acquisition & Technology)

Defense Technical Information Center

8725 John J. Kingman Road, Suite 0944

Ft. Belvoir, VA 22060-6218

Federal Government agencies and their contractors registered with the Defense Technical Information Center should direct requests for copies of this report to:

TECHNICAL REVIEW AND APPROVAL

NMRI 95-76

The experiments reported herein were conducted according to the principles set forth in the current edition of the "Guide for the Care and Use of Laboratory Animals," Institute of Laboratory Animal Resources, National Research Council.

This technical report has been reviewed by the NMRI scientific and public affairs staff and is approved for publication. It is releasable to the National Technical Information Service where it will be available to the general public, including foreign nations.

THOMAS J. CONTRERAS
CAPT, MSC, USN
Commanding Officer
Naval Medical Research Institute

REPORT DOCUMENTATION PAGE

Form Approved OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing his burden, to Washington Headquarters Services, Directorate for information Operations and Reports, 1215 Jefferson Caush High Pays. Suite 1204, Arington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

| Lavis Righway, suite 1204, Anington, va. 22202 | | a bodget; - bpermora neodetion | 3 |
|--|---|--------------------------------|--|
| 1. AGENCY USE ONLY (Leave blan. | k) 2. REPORT DATE | 3. REPORT TYPE AN | D DATES COVERED |
| | December 1995 | Technical 8 | /94 - 10/95 |
| 4. TITLE AND SUBTITLE | | | 5. FUNDING NUMBERS |
| Evaluation of portable | | zers for use at | PE - 63713N |
| 1 ATA on U.S. Navy subr | marines. | | PR - MOO99 |
| 5 AUTUO P/6\ | | | TA01A/.01C |
| 6. AUTHOR(S) | | | WU - 5201/1506 |
| Lillo, R.S., A. Ruby, V | N.R. Porter, J.M. Cal | dwell | WO - 5201/1506 |
| | | | |
| 7. PERFORMING ORGANIZATION NA | ME(S) AND ADDRESS(ES) | | 8. PERFORMING ORGANIZATION |
| Naval Medical Research Ins | stitute | | REPORT NUMBER |
| Commanding Officer | | | |
| 8901 Wisconsin Avenue | • | | nmri 95-76 |
| Bethesda, Maryland 20889-5 | 5607 | | |
| * | | | |
| 9. SPONSORING/MONITORING AGE | | 5) | 10. SPONSORING / MONITORING AGENCY REPORT NUMBER |
| Naval Medical Research and | | | AGENCY REPORT NOWIBER |
| National Naval Medical Cer | nter | | DN242606/DN241125 |
| Building 1, Tower 12 8901 Wisconsin Avenue | | | • |
| Bethesda, Maryland 20889-5 | 5404 | , | |
| 11. SUPPLEMENTARY NOTES | 1000 | | |
| | | | |
| | | | |
| | | | |
| 12a. DISTRIBUTION / AVAILABILITY S | TATEMENT | | 12b. DISTRIBUTION CODE |
| | | • | |
| Approved for public release | e; distribution is unlimited. | | |
| | | | |
| | | | |
| | | | |
| 13. ABSTRACT (Maximum 200 words | • | | |
| | Research Institute (NMI | | |
| Medical Research Laborate | ory (NSMRL) in August | 1994 to evaluate po | rtable carbon dioxide |
| analyzers for use at 1 ATA | A on U.S. Navy submarir | nes. A plan for selec | tion and testing of |
| candidate analyzers was de | eveloped by NMRI and a | pproved by NSMRI | prior to start of work |
| Candidate analyzers were | chosen based on desired | requirements marke | et search and preliminary |
| testing. Five candidates we | ere selected to undergo th | requirements, marke | precision short town |
| | | | |
| accuracy, long-term (up to | 90 days) accuracy, and | effect of interfering | gases and ambient |
| temperature. Based on test | ing results, a non-dispers | ive infrared instrum | ent, CDM-1000/long, |
| manufactured by Geotechn | iical Instruments, Inc., is | recommended as the | e best candidate for use on |
| Navy submarines. | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| 14. SUBJECT TERMS | | | 15. NUMBER OF PAGES |
| air purity, carbon diox | | | es, |
| diving gas, gas analysi | s, gas purity, infra | red, submarines | 16. PRICE CODE |
| | 0 00010174 01 400171047104 | 19. SECURITY CLASSIFIC | ATION 20. LIMITATION OF ABSTRACT |
| 17. SECURITY CLASSIFICATION 1 OF REPORT | 8. SECURITY CLASSIFICATION OF THIS PAGE | OF ABSTRACT | ATION 20. CHARTATION OF ADSTRACT |
| Unclassified | Unclassified | Unclassified | Unlimited |

TABLE OF CONTENTS

| | page |
|---|----------------|
| ACKNOWLEDGEMENTS | iii |
| BACKGROUND | 1 |
| EVALUATION PLAN | 1 |
| Requirements | 2 |
| METHODS | 5 |
| Laboratory testing | 10 |
| RESULTS AND DISCUSSION | 12 |
| Precision | 13 14 14 |
| SUMMARY AND RECOMMENDATIONS | 16 |
| Operating procedures for the recommended analyzer | 17 |
| REFERENCES | 18 |
| FIGURE LEGENDS | 30 |
| List of Tables | |
| Table 1. Precision Testing Results | 19 |
| Table 2. Short-term and Long-term Testing Results | 20 |

List of Figures

| Figure 1. Testing Setup | 32 |
|---|----|
| Figure 2. Short-term Accuracy | 33 |
| Figure 3. Response Curves | 38 |
| Figure 4. Long-term Accuracy | 43 |
| Figure 5. Ambient Temperature | 48 |
| List of Appendices | |
| Appendix A. Instrument Review and Selection | 49 |
| Companies contacted but analyzers rejected | 71 |
| Appendix B. Field Testing Protocol | 75 |
| CO ₂ Sampling Data Sheet | 79 |
| Appendix C. Operating Procedures for the Recommended Analyzer, Geotechnical CDM-1000/long | 80 |

ACKNOWLEDGEMENTS

This work was supported by Naval Medical Research and Development Command Work Unit Nos. 63713N M0099.01A-5201 and 63713N M0099.01C-1506.

The opinions expressed in this paper are those of the authors and do not reflect the official policy or position of the Department of Navy, Department of Defense, or the U.S. Government.

BACKGROUND

The Naval Medical Research Institute (NMRI) was tasked by the Naval Submarine Medical Research Laboratory (NSMRL) in August 1994 to evaluate portable carbon dioxide (CO_2) analyzers for use on U.S. Navy submarines. These analyzers would be used at normal submarine pressures (i.e., ~ 1 ATA) to measure CO_2 levels in air throughout shipboard spaces. Such analyzers would supplement the current CAMS-I, the on-board gas analyzer, which is limited to a specific number of sampling sites and not designed to measure low CO_2 concentrations (e.g., < 0.2%). These instruments could also replace the CO_2 detector tubes that are used on a weekly basis but are not known to be very reliable.

EVALUATION PLAN

A plan for selection and testing of candidate analyzers was developed by NMRI and approved by NSMRL prior to start of work. This plan included the requirements of the desired analyzer, as well as detailed procedures for evaluating performance.

Requirements

1. Essential

- a. Measurement range: 0 to 7.5% CO₂ (sub escape limit); may require more than 1 instrument to span range.
 - b. Ambient Temperature range: 20 to 40 °C.
- c. Interferences: accuracy limits met with sample concentrations of total hydrocarbons up to 90-day limit and CO, hydrogen, and Freons up to 1 h limits.

2. Desired but non-essential

- a. Short-Term Repeatability (within 10 min): \pm 5% relative over range 0.1% to 7.5% CO_2 .
- b. Short-Term Accuracy (within 10 min of calibration): \pm 10% relative over range 0.1% to 7.5% CO₂.
- c. Long-Term Accuracy (up to 90 days after calibration): \pm 25% relative over range 0.1% to 7.5% CO₂.
 - d. Response time: less than 30 s to 95% of reading.
 - e. Physical dimensions: volume less than 0.5 cubic foot.
 - f. Task appropriate: rugged, corpsman friendly, low cost.

Selection of candidate analyzers

Candidate analyzers would be selected based on a market search, manufacturer specifications, demonstrations, and preliminary testing by NMRI.

- 1. *Market search*. The market search consisted of a review of product literature obtained from vendors, attending of analytical exhibits at meetings, and requested demonstrations by vendors.
- 2. *Preliminary testing*. Such testing was performed by NMRI at in-house demonstrations by vendors and using loaned units.
- 3. Selection. Appendix A provides detailed information regarding instruments reviewed resulting in 5 candidate analyzers being chosen for formal testing by NMRI. All use non-dispersive infrared detection as their method of analysis. The 5 analyzers are listed below:

a. Model CD-1300-P, Enmet Corp.

0 to 10% CO₂

Analog readout

Zero and span adjustment

b. Model RIKEN RI-411A, RKI Instruments, Inc.

0 to 9.95% CO_2

Digital readout

Zero and span adjustment

Fixed scale, X.XX (last decimal last reads in 0.05

increments)

c. Model 302 BD, NOVA Analytical Systems, Inc.

0 to 10% CO₂

Digital readout

Span adjustment, no zero adjustment

Fixed scale, X.X

d. Model CDM-1000/long, Geotechnical Instruments, Inc.

0 to 7.5% CO₂

Digital readout

Span adjustment, no zero adjustment

Variable scale, X.XXX for 0 to 0.999, X.XX for 1.00 to 8.00

Long = long pathlength cell

e. Model CDM-1000/short, Geotechnical Instruments, Inc.

0 to 7.5% CO₂

Same specifications as CDM-1000/long

Short = short pathlength cell

To facilitate discussion, these analyzers will be referred to in this report as Enmet, RKI, Nova, GeoL, and GeoS, respectively.

Summary of testing procedures

One of each of the 5 candidate analyzers was tested for the following:

1. *Precision* (short-term repeatability)

Calibrated instruments were presented with the same mixture multiple times over a 10-minute period and variability noted. This was done with a range of CO₂ concentrations and on multiple occasions.

2. Short-term accuracy

Calibrated instruments were presented with a range of mixtures over 20-30 min and the difference noted between actual value and measurement. This reflected both precision and linearity of instrument and was also limited by error in the test gases. The longer test time vs. the initial 10-minute requirement was necessary as complete concentration-response curves were generated as discussed below.

3. Long-term accuracy

Short-term accuracy tests were repeated up to 90 days without re-calibration. This reflected short-term accuracy and long-term drift of instrument calibration (i.e., zero and gain).

4. Interfering gases

Precision and short-term accuracy tests were repeated with a range of CO₂ calibration mixtures containing carbon monoxide, hydrogen, Freons, and aromatic and aliphatic hydrocarbons. Interfering gas concentrations were chosen based on 1-hour submarine limits for the first 3 species and 90-day limits for the hydrocarbons, as 1-hour limits have not been established.

5. Ambient temperature

Effect of ambient temperature on analyzer measurement was examined from ~ 10 °C to ~ 35 °C.

6. Field testing

Determination of suitability for use in submarine environments and degree of "sailor friendliness" was made by field testing on 1 submarine.

7. Interpretation of results

Pass/fail criteria for analyzer performance is given under Requirements section above.

Criteria for judging suitability for use by submariners and use in a submarine environment were based on Requirements and also included feedback from field testing.

METHODS

All laboratory testing, except that under the section Ambient Temperature, was done at temperatures normally between 19 and 24 °C. However, during the latter part of the long-term accuracy test, laboratory temperatures occasionally ranged up to 30 °C due to air conditioning problems. Changes in barometric pressure were ignored.

Laboratory testing

The following gases were used during testing:

Zero gas: CO₂-free, hydrocarbon-free air.

Span gases: Four primary gravimetric standards: 0.25%, 2.5%, 5.0%, and 10% CO_2 , all in balance hydrocarbon-free air and certified to \pm 1% relative.

Gas was delivered to the analyzers using a precision gas divider (STEC model SGD-710, Horiba Instruments, Inc., Ann Arbor, MI). The STEC device allowed blending of the 4 CO_2 standards with a diluent gas (hydrocarbon-free air) in 10 equal steps from 0 to 100% of the original CO_2 concentration. This divider has been previously shown to be linear to within the manufacturer's specification of \pm 0.5% of full scale, using 5 to 100 ppm levels of a number of volatile organic compounds (1-2) and up to 25% of fixed gases (e.g., O_2 , CO_2). In this way, accuracy of analyzers could be tested over entire calibration curves (0 to 100% of each test mixture) rather than only at the 4 concentrations of the mixtures. The only exception was for the 10% CO_2 gas where the maximum STEC setting used was 80% resulting in a maximum CO_2 concentration of 8%. The Enmet and Nova analyzers were not tested with the lowest CO_2 standard, 0.25%, as the first instrument's analog display did not resolve such low concentrations and the second instrument's digital display did not go below 0.1%.

Teflon tubing was used to connect the standards and diluent gases to the STEC. Widebore (1/4-inch inner diameter) Tygon tubing containing a tee was used to deliver gas to the inlet port of the analyzer. Gas flow was adjusted so that a slight excess flow was delivered resulting in several liters/min leaving the overflow (Fig. 1). In this manner, gas was sampled without pressurizing the instrument.

1. Precision

- a. Instrument was turned on and allowed warmup time per instrument manual.
- b. Instrument was calibrated per instructions in manual. Hydrocarbon-free gas was used as the zero gas where zero gas was required. One of the four 4 $\rm CO_2$ standards was used as the span gas with STEC at 100% (except STEC = 80% for 10% $\rm CO_2$ standard).
 - c. One minute was waited.
 - d. Zero gas was sampled and measurements taken when stabilized.
 - e. Span gas was sampled and measurements taken when stabilized.
- f. Steps d-e were repeated every 2 min for a total of 5 times during which calibration controls were not touched.
 - g. Steps b-f were repeated for the other 3 CO₂ standards.
 - h. This test was done at the beginning of each short-term accuracy test (below).

2. Short-term accuracy

- a. Instrument was turned on and allowed warmup time per manual.
- b. Instrument was calibrated per manual using 1 of the 4 span gases and zero gas (if required).
 - c. One minute was waited.
- d. STEC setting was varied from 0 to 100% of span gas and back to 0% (0 to 80% and back to 0% of span for 10% $\rm CO_2$ standard) and measurements taken when stabilized.
 - e. Steps b-d were repeated for the other 3 CO₂ standards.
 - f. This test was run weekly for a total of 4 weeks.
 - g. Minimum test concentration was 0.025% CO₂ (STEC=1 for 0.25% CO₂).

3. Long-term accuracy

- a. This testing was started after all precision and short-term testing had been completed.
- b. Testing, as per short-term accuracy, was repeated weekly for a total of 13 weeks, but analyzer was calibrated only once at the start of the first week's test using 8% CO₂.

4. Interfering gases

- a. Precision and short-term accuracy testing were repeated using each of the following5 gravimetric standards, all prepared in hydrocarbon-free air, as the diluent gas for STEC:
 - (1) ~1000 ppm CO
 - (2) ~1% Hydrogen
 - (3) ~3000 ppm Freon 114
 - ~3000 ppm Freon 12
 - (4) ~10 ppm Toluene
 - $(~38 \text{ mg/m}^3)$
 - (5) ~50 ppm Octane
 - $(\sim 230 \text{ mg/m}^3)$

The listed concentrations are the nominal values that were certified to $\pm 2\%$ of reported values.

b. These gases were chosen based on the following limits from the Submarine Atmosphere Control Manual (3):

| | Limit | is |
|------------------------------|---------------|---------------------|
| | <u>1 hour</u> | <u>90 day</u> |
| Carbon monoxide | 400 ppm | |
| Hydrogen | 1% | |
| Freon 12 | 2000 ppm | |
| Freon 114 | 2000 ppm | |
| Total aromatic hydrocarbons | NE | 10 mg/m^3 |
| (less Benzene) | | C |
| Total aliphatic hydrocarbons | NE | 60 mg/m^3 |
| (less methane) | | C |

NE = limit has not been established.

- c. As the STEC setting was varied from 0 to 100%, the resulting interfering standard concentration in the gas going to the analyzer would change from 100 to 0% of its prepared value. In this way, contaminant concentrations would bracket the actual submarine limits given above.
- d. No effect by the testing setup (e.g., absorption by the tubing) on the volatile organic mixtures (Freons, octane, and toluene) was detected. This was shown by sampling gas upstream and downstream of the setup using the TVA-1000 portable toxic vapor analyzer (Foxboro Co., East Bridgewater, MA).
- e. To expedite completion of our study, this test was done once during the period when long-term accuracy testing was being done.

5. Ambient temperature

- a. All 5 instruments were turned on and allowed to warm up for 15 min.
- b. Instruments were calibrated with 8% CO₂ at laboratory temperature (19-21 °C).
- c. Analyzers were placed into a small animal hyperbaric chamber which was at laboratory temperature, and the door closed although not sealed to hold pressure.

- d. A hull penetrator allowed gas to be delivered to the instruments in usual fashion. Chamber temperature was regulated to \pm 0.5 °C using a temperature-controlling unit (Yellow Springs Instrument Co., Yellow Springs, OH).
- e. Initial instrument readings were taken for zero air and 8% CO₂ at laboratory temperature by looking through the chamber viewport.
- f. The temperature controller was adjusted to maximum cooling or heating and allowed to stabilize for 2 h.
 - g. Measurements were then taken again for zero air and 8% CO₂.
- h. The temperature controller was then adjusted to the maximum opposite setting, and after 2 h, measurements were again taken.
- i. The controller was then set back to room temperature, and measurements were repeated after 2 h.
 - j. Five complete tests were done on separate days with all analyzers tested together:
 - (1) Two tests going first to cold and then to hot
 - (2) Two tests going first to hot and then to cold
 - (3) One test remaining at laboratory temperature for 6 h as a control.
- k. Minimum and maximum chamber temperatures that could be obtained with the NMRI setup were ~ 10 °C and ~ 35 °C.

Field testing

Field testing of the recommended instrument was done by ship's personnel on the USS James K. Polk (SSN-645) during a 19-day period from 13 September to 1 October 1995.

During this period, the submarine went out to sea twice. Detailed procedures are given in

Appendix B.

This testing was designed to evaluate:

- 1. Stability of the instrument under actual submarine conditions.
- 2. Potential problems with the draft operating procedures.
- 3. How the CO₂ measurements of the analyzer compare to those from the CAMS-I.
- 4. Sailor "friendliness" of the instrument.

To summarize procedures, the analyzer was calibrated with 8% CO₂ at NMRI on 8 August 1995 prior to delivery to the submarine. During the actual field test, analyzer calibration was checked, but <u>not recalibrated</u>, once daily prior to use by measuring the CAMS-I calibration gas mixture (containing ~1.3% CO²) carried on all submarines. Following the calibration check, CO₂ measurements were taken with the analyzer once at up to 11 locations on the submarine that could also be sampled by the CAMS-I. Analyzer and CAMS-I (CO₂ and total pressure) measurements were taken simultaneously by using 2 people and shipboard communication. Analyzer readings were recorded when stable with the instrument positioned immediately next to the inlet of the CAMS-I sampling line.

Analyzer measurements were not corrected for the small changes in total pressure on the submarine. CAMS-I CO_2 and total pressure readings were displayed and recorded to the nearest 0.1 and 1 torr respectively. CAMS-I percent CO_2 was calculated as follows:

$$%CO_2 = CAMS-ICO_2(torr)$$
 • 100 • 100 • CAMS-I pressure (torr)

Following the field test, the analyzer was returned to NMRI where instrument response to 0 to 8% CO₂ was determined, both before and after recalibration with 8% CO₂, using the

STEC device.

Data analysis

Means and relative standard deviations were calculated from the precision data. Short-term and long-term accuracy data were used to calculate relative percent error:

Expected reading was determined by multiplying the certified value of the CO_2 standard by the STEC setting (i.e., 0 to 100%).

As discussed above, testing with interfering gases was done during the same period as long-term testing, making re-calibration prior to testing impossible. Therefore, the gas effect was judged by calculating the difference between the measurement errors while using the interfering gases and the errors determined during the long-term test done the same week.

For Ambient Temperature data, instrument drift during cold and hot exposures was calculated relative to the initial lab temperature in the following manner:

Drift (%
$$CO_2/^{\circ}C$$
) = Reading at test temperature (cold or hot) - Initial reading
Test temperature - Initial lab temperature

Percent Drift (%/°C) =
$$\frac{\text{Drift} \cdot 100}{\text{Initial reading}}$$

RESULTS AND DISCUSSION

Precision

Results are given in **Table 1**. Some data for the lower concentration gases are missing from the table for the following reasons: a) the Enmet and Nova instruments were not tested

with the lowest concentration standard for reasons given above and b) problems arose with acquisition of some of the gases and some of the instruments at the start of this study.

With the exception of the Enmet with analog readout, relative standard deviations based on 5 measurements over 10 min was \leq 2% for all instruments down to 2.5% CO₂. No problem with zero drift was observed with any instruments.

Conclusion: All analyzers, except the Enmet, met the 5% precision requirement using 2 relative standard deviations as an index of precision.

Short-term accuracy

All analyzers, with the exception of the Enmet, had a relative error of $\leq 10\%$ for measurements from 8% down to ~1%. (Table 2; Fig. 2). Calibration with lower concentration standards improved measurement at lower levels. The GeoL and GeoS worked well ($\pm 10\%$) down to ~0.25%, although at these levels small absolute errors translated into large relative errors. No problem with zero drift was observed with any instruments.

Representative response curves for each instrument for the 4 CO₂ standards are given in Fig. 3. As testing took place immediately after calibration, these curves would represent the "best-case" in terms of error.

Conclusion: The GeoL and GeoS analyzers were the best analyzers in terms of meeting the 10% accuracy requirement from 8% down to ~0.25%. The Enmet did not meet the requirement, even at the higher concentrations.

Long-term accuracy

All analyzers, except the Enmet, completed the long-term testing over 13 weeks (Table 2). The Enmet was eliminated from the test after 11 weeks after repeatedly exceeding the

25% accuracy requirement. All instruments, except the Enmet, met the accuracy limit at concentrations from 8% down to ~0.5-1%. No problem with zero drift was observed with any instruments. Procedural error during Week 6 resulted in loss of data and calibration in the GeoL and GeoS. Consequently, both instruments were re-calibrated prior to Week 7's test.

Fig. 4 summarizes the data well and suggests negligible effect of re-calibration on the test (i.e., compare Weeks 6 and 7 results). The clear leader in terms of long-term accuracy is the GeoL. The GeoL met the accuracy requirement down to concentrations < 0.05%, quite a remarkable feat.

Conclusion: The GeoL was clearly the best analyzer in terms of long-term accuracy following a one-time initial calibration with 8% CO₂.

Interfering gases

Differences between measurement errors with and without interfering gases were generally < 10% for the 4 instruments tested. This error is similar to short-term accuracy and thus an effect due to any of the 5 gases could not be detected. The ability to detect small effects due to gas was limited by doing this testing during the long-term accuracy test period when calibration was not permitted. However, any such effects should be inconsequential in terms meeting the relatively liberal accuracy requirements. The Enmet was not tested as it had been excluded after failure during the long-term accuracy test.

Conclusion: All 4 analyzers appeared to be unaffected by the interfering gases.

Ambient temperature

All instruments showed temperature drifts up to \pm 0.2% CO₂/°C, which translate to \pm 3% of the test concentration reading (Fig. 5). This effect dropped to \pm 0.1% CO₂/°C and

 \pm 1% of test reading if the Nova analyzer is omitted. The Enmet instrument was not tested, as it had been eliminated from the study by the time this last phase was done. Average starting, cooling, and heating temperatures were approximately 20 °C, 12 °C, and 34 °C. During the control test where ambient temperature was held constant (20.0 °C \pm 0.5), analyzer measurements changed from starting values up to \pm 0.3% CO₂ over 6 h. No problem with zero drift was observed with any instruments.

Conclusion: The RKI, GeoL, and GeoS responded to changes in ambient temperature similarly. The Nova was slightly more responsive to heating and cooling which would be a negative factor against its selection. Calibration of any of the first 3 instruments at normal room temperatures (18-24 °C) should result in acceptable accuracy when used at ~10 to 35 °C.

Field testing

During the 10 days of actual testing, daily measurement of the 1.353% CO₂ CAMS-I calibration gas using the recommended instrument (GeoL, see below) ranged from 1.350 to 1.420% CO₂. CAMS-I measurements from the various compartments of the submarine ranged from 0.27 to 1.02% CO₂ with total pressure within the various compartments from 747 to 791 torr. Differences between CAMS-I and GeoL measurements ((CAMS-I) - GeoL) ranged from -0.14 to 0.08% CO₂. On average, CAMS-I values were 0.05% CO₂, or ~9% of reading, lower than those of the GeoL.

NMRI testing following return of the instrument suggested that a shift in the calibration of the analyzer had occurred. This shift resulted in relative error lowest when measuring 1% CO₂ and increasing up to ~18% error as the CO₂ in the test gas was raised to 8%. Such performance would be expected if the instrument had been recalibrated with the

1.3% CO₂ CAMS-I calibration gas sometime <u>during</u> the field test. Ship's personnel indicate this had not occurred. Additional field testing would be needed to resolve this issue and determine if long-term accuracy as measured in the lab is a reliable measure of long-term accuracy in the field.

Ship's personnel reported no problems with the GeoL and were very enthusiastic about it.

Conclusion: The GeoL, the recommended analyzer, performed well during field testing although a shift in the calibration appears to have occurred during the test. Additional field testing would be needed to clarify this issue.

SUMMARY AND RECOMMENDATIONS

All 5 candidate analyzers completed all aspects of the original test plan. It is emphasized that recommendations are based on testing results from only 1 analyzer from each of the 5 candidates.

The Enmet unit failed the precision, short-term, and long-term accuracy tests and was difficult to calibrate. It had intermittent periods in which it did not operate at all and was rejected as unreliable.

The <u>RKI</u> unit was not as accurate over the long term as the GeoL and GeoS, but met all of the test requirements. It is easy to calibrate and to use.

The <u>Nova</u> unit is considerably larger than the others, but has excellent performance characteristics. Calibrating this analyzer requires patience and a short learning curve. Once mastered, it can be easily done. The major objection is that it is bulky to handle. It passed all

of the test requirements, although its response to ambient temperature is greater than the other analyzers.

Two 0 to 7.5% Geotechnical units were tested, one with a long pathlength cell (GeoL) and one with a short pathlength cell (GeoS). Both analyzers performed flawlessly. Operation is simple and calibration is easy. The size and weight are both good. The instruments met all of the test requirements. The GeoL had better accuracy at the lowest concentrations and is recommended as the best candidate for use on U.S. Navy submarines. The GeoL performed well during field testing, although additional testing is recommended.

Operating procedures for the recommended analyzer

Operating procedures for the recommended analyzer, Geotechnical CDM-1000/long are given in Appendix C.

REFERENCES

- 1. Lillo, R.S., Caldwell, J.M. <u>Preliminary evaluation of a halogen leak detector for screening divers' breathing air</u>. NMRI Technical Report No. 89-108, Naval Medical Research Institute, Bethesda, MD, 1989.
- 2. Lillo, R.S., Ruby, A., Gummin, D.D., Porter, W.R., Caldwell, J.M. <u>Analysis of volatile contaminants in U.S. Navy fleet soda lime</u>. NMRI Technical Report No. 95-39, Naval Medical Research Institute, Bethesda, MD, 1995.
- 3. U.S. Naval Sea Systems Command. <u>Nuclear powered submarine atmosphere control</u> manual. NAVSEA S9510-AB-ATM-010/(U). Vol. 1, rev. 2. 30 July 1992.

Table 1 Precision Testing

| | ÷ | Week 1 Calibrated | Week 2 Calibrated | Week 3 Calibrated | Week 4 Calibrated |
|--------|------------------------------------|---------------------------------------|---------------------------------------|---------------------------------------|---------------------------------------|
| Enmet | Mean R.S.D. (%) Range | 9.5 | 8.0 0.69 7.9 - 8.0 | 7.8 2.64 7.5 - 8.0 | 7.7 1.75 7.6 - 7.9 |
| Z Z | Mean R.S.D. (%) Range | 8.100 0.00 | 7.970 0.56 7.950 - 8.050 | 8.070 0.83 7.950 - 8.100 | 8.060 0.28 8.050 - 8.100 |
| Nova | Mean R.S.D. (%) Range | 8.1 1.03 8.0 - 8.2 | 8.1 1.03 8.0 - 8.2 | 8.0 0.00 | 8.1 0.00 |
| GeoL | Mean R.S.D. (%) Range | 8.104 0.40 8.080 - 8.160 | 8.140 0.39 8.100 - 8.180 | 8.088 0.67 8.020 - 8.170 | 7.970 0.50 7.920 - 8.020 |
| GeoS | Mean R.S.D. (%) Range | 8.004 0.23 7.980 - 8.030 | 8.152 0.54 8.110 - 8.220 | 8.110 0.29 8.080 - 8.130 | 7.900 0.39 7.870 - 7.950 |

2.5% CO2

| | | Week 1 Calibrated | Week 2 Calibrated | Week 3 Calibrated | Week 4 Calibrated |
|-------|-----------------------------|---------------------------------------|---------------------------------------|---------------------------------------|---------------------------------------|
| Enmet | Mean R.S.D. (%) Range | | 1 1 1 | 2.4 5.10 2.2 - 2.5 | 2.5 |
| Ξ | Mean R.S.D. (%) Range | 2.450 0.00 | 2.470 1.81 2.400 - 2.500 | 2.450 1.44 2.400 - 2.500 | 2.480 1.10 2.450 - 2.500 |
| Nova | Mean R.S.D. (%) Range | | | 2.5 2.16 2.5 - 2.6 | 2.5 |
| GeoL | Mean R.S.D. (%) Range | 2.472 0.34 2.460 - 2.480 | 2.482 0.34 2.47-2.49 | 2.480 0.49 2.470 - 2.500 | 2.480 0.81 2.450 - 2.500 |
| GeoS | Mean R.S.D. (%) Range | 2.490 0.00 | 2.482 0.18 2.480 - 2.490 | 2.482 0.72 2.450 - 2.490 | 2.486 0.22 2.480 - 2.490 |

R.S.D. = Relative Standard Deviation

(n = 5 in all cases)

5% CO2

| | | | | • | |
|-------|------------|----------------------|----------------------|-----------------------------|----------------------|
| | | Week 1 Calibrated | Week 2 Calibrated | Week 3 Calibrated | Week 4 Calibrated |
| | | | | | |
| Enmet | Mean | 4.9 | 5.0 | 5.1 | 5.0 |
| | R.S.D. (%) | 0.91 | 0.90 | 0.88 | 0.00 |
| | Range | 4.9 - 5.0 | 4.9 - 5.0 | 5.0 - 5.1 | , |
| 2 | | 000 | 1 | 0.00 | 000 |
| Z | Mean | 5.036 | 5.100 | 5.010 | 2.090 |
| | R.S.D. (%) | 0.33 | 0.00 | 0.83 | 0.44 |
| | Range | 5.010 - 5.050 | • | 4.950 - 5.050 | 5.050 - 5.100 |
| | | | | | |
| Nova | Mean | 5.0 | 5.0 | 5.1 | 5.0 |
| | R.S.D. (%) | 0.00 | 0.00 | 0.88 | 0.00 |
| | Range | • | | 5.0 - 5.1 | • |
| Coc | Moon | 5.056 | 5 030 | 5.036 | 5038 |
| 2 | | 36.5 | 55.5 | 0000 | 20.0 |
| | H.S.D. (%) | 0.36 | 0.58 | 0.33 | 0.39 |
| | Range | 5.030 - 5.080 | 5.010 - 5.080 | 5.010 - 5.050 | 5.010 - 5.050 |
| | | | | | |
| GeoS | Mean | 5.042 | 5.024 | 5.036 | 5.032 |
| | R.S.D. (%) | 0.17 | 0.36 | 0.23 | 0.33 |
| | Range | 5.030 - 5.050 | 5.000 - 5.050 | 5.020 - 5.050 5.010 - 5.050 | 5.010 - 5.050 |
| | | | | | |

0.25% CO2

| | | Week 1 Calibrated | Week 2 Calibrated | Week 3 Calibrated | Week 4 Calibrated |
|-------|------------------------------------|----------------------|----------------------|---------------------------------------|---------------------------------------|
| Enmet | Mean R.S.D. (%) Range | | | | |
| Ж | Mean R.S.D. (%) Range | 0.300 | 0.300 | 0.300 | 0.300 |
| Nova | Mean R.S.D. (%) Range | | | 1 1 1 | 1 1 1 |
| GeoL | Mean R.S.D. (%) Range | | | 0.255 0.75 0.253 - 0.258 | 0.255 0.70 0.252 - 0.256 |
| GeoS | Mean R.S.D. (%) Range | | | 0.254 0.99 0.252-0.258 | 0.259 0.50 0.257 - 0.260 |

Table 2A Enmet Short-term and Long-term Testing

| | | Γ- | _ | | | П | | _ | Т | | 1 | | | Ι | | T | | _ | Т | | 1 | _ | _ |
|-----------------|----------------|---------------------------|----------|------------|-----|-----|-----|----|-----|-----|-----|----------------|-----|----------------|--------------|-----|-----|-----|----------|-----------|-----|-----|---------|
| | | Mook 15 | ממע ויי | | | | • | | | | | | • | ١. | | | | • | | | | | |
| | | Wook 12 | 7 4001 | | | | , | • | | | | | | | | | | | ١, | | | | • |
| • | | Week 11 Week 12 West 19 | T NOOL | 04/20/95 | | 3 | \$ | 89 | 30 | 3.5 | 4 6 | ₹! | 27 | 23 | | ,,, | ę | 22 | 30 | ÷ | 3 | 4 | 99 |
| | | Week 10 | 2 4000 | 04/12/95 | | 3 | 55 | 47 | 43 | 90 | 2 5 | ŝ | ð, | 23 | *** | 5 3 | \$ | 37 | 38 | • | 3 | 32 | 8 |
| | | Week 9 | 20000 | 04/05/95 | ٠, | ⊋ | 8 | ຄ | 23 | £ | 2 | - 6 | 2 | 17 | ξ | 3 4 | 2 : | 18 | 50 | ç | 73 | 3 | \$ |
| | | Week 8 | 10,00,00 | 03/05/60 | c | ٥ | 0 | 0 | 0 | c | , | ٥ د | ٥ | 9 | ď | | ۰ د | -5 | 0 | | | > | 0 |
| | | Week 7 | 30/00/00 | 03/20/33 | c | | 0 | 0 | 0 | ٩ | | ų . | - | υ | c | , , | , (| 2 | τ'n | ۲ | , | ņ | 0 |
| | | Week 6 | 03/46/05 | 26/01/20 | c | | o : | 0 | 0 | ç | 0 | o q | | 'n | cr. | , | , (| 7- | 0 | c | | > | 0 |
| | | Week 5 | 30/00/60 | 2000 | ç | 2 | n (| 3 | 0 | ۲. | ır | | 2 | 4 | œ | , | 1 (| 7- | 0 | c | Ş | 2 | 0 |
| • | | Week 4 | 03/02/05 | | ç | 2 | n | 5 | ı, | 4 | 7 | , , | 2 | = | 7 | ď | | 7 | 0 | c | 4 | · ! | 우 |
| · | Test | Week 3 | 02/24/95 | | c | | > 0 | 2 | 8 | N | L. | 9 (2 | , | 9 | 9 | ç | ء ا | | 0 | 0 | | ٠ د | 0 |
| 1 | Long Term Test | Week 2 | 02/15/95 | | ę | 2 4 | | 2 | α | Q | 7 | ď | , | S | 9 | ٠. | | | N | ო | ď | , ; | 10 |
| • | | Week 1 | 02/10/95 | Calibrated | -10 | 5 | 2 1 | | ιċ | 9- | 6- | - | , | 7 | - | ę | ې | · | - | | ę- | 2 5 | - |
| | | Week 4 | 02/03/95 | Calibrated | -10 | ų | , 1 | | ဟု | မှ | ņ | - | | _ | - | -3 | ď | , | , | ņ | ż. | | |
| | | Week 3 | 01/27/95 | Calibrated | -20 | ÷- | ۲. | | -10 | 27- | 2- | -7 | , | † | .3 | -10 | £- | 9 | 2 - | | r. | , , | > |
| Toot | 1621 | Week 2 | 01/18/95 | Calibrated | -20 | -15 | 7 | | £1- | -12 | 9- | œρ | 7 | | æ | ٠, | Ç. | Ş | ? : | -13 | -20 | 50 | 72. |
| Short Torm Toot | | Week 1 | 01/09/95 | Calibrated | -10 | -10 | .7 | | ا م | | φ | 7 | | , (| | φ | ۲- | 9 | PI | <i>)-</i> | -10 | ц | ; |
| | _ | | Expected | 0.0 | 1.0 | 2.0 | 30 | | 4 r | 5.7 | | 7.1 | ÷ α | - 7 | - | 6.1 | 1.0 | C 7 |) (| 3.0 | 5.0 | - | 9 9 |
| 10 1% CO2 | 2 | į | Stec | 0 | 9 | 8 | 8 | Ş | ş (| 8 | 8 | 70 | æ | 8 8 | ? | 9 | 23 | 8 | 2 6 | 3 | ଷ | £ | 2 6 |

| 5.04% CO2 | C02 | | | | | | | | | | | | | | | | | |
|------------|------------|------------|----------------|------------|------------|------------|----------|----------|----------|----------|----------|----------|----------|------------|----------|----------|---------------------------------------|-----|
| ı | ı | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Wook 11 | Week 11 Mock 12 Mock | 100 |
| Stec | Expected | | 01/18/95 | 01/26/95 | 02/03/95 | 02/10/95 | 02/15/95 | 02/24/95 | 03/02/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/31/95 | 04/05/95 | 04/12/05 | 04/20/06 | 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 5 |
| 0 | 0.0 | Calibrated | Calibrated | Calibrated | Calibrated | Calibrated | | | | | | | | 2000 | 26.0 | CE/NZ/AD | | • |
| 9 | 0.5 | -54 | -21 | Ŧ | - | -5 | -21 | - | - | - | • | + | č | 20 | | VII. | | • |
| ଛ | 1.0 | ** | -21 | - | - | ÷ | - | - | | | - - | | 13. | 80 | â | 8 | | 1 |
| 8 | 1.5 | -7 | -14 | -7- | -7- | . 7 | - ^ | - u | - u | 7 0 | - • | _ 1 | _ ! | 68 | 39 | 20 | | • |
| 4 | 00 | ÷ | ¥ | | | | | | | | - | ,- | ,- | 33 | 32 | 46 | | ١ |
| . <u>.</u> | 9 5 | . ų | | , u | ρu | | - , | 4 (| - (| | | - | - | 8 | 82 | 39 | , | ' |
| 8 | | 1 | 2 | , | ٩ | ç | - | | 6 | က | - | - | rὑ | 23 | 23 | 35 | , | • |
| 3 : | 3.0 | | | 4 | _ | 2- | - | ო | ო | - | - | - | - | 4 | 96 | 30 | | |
| 2 | 3.5 | -8 | G, | 4 | 4 | φ | - | ur. | ٥ | - | · • | | - + | 2 \$ | 70 | 7 6 | | • |
| 8 | 4.0 | | -11 | 6 | 5 | 6- | - | 4 | - | - | - | - , | - , | 2 6 | 2 | G. | - | ' |
| 8 | 4.5 | φ | -10 | ņ | ņ | ı, | | · u | | + + | - • | - • | - , | 3 7 | 57 | ģ | | ' |
| 100 | 5.0 | l | q |) - | , | , | - - | 2 | + | - | - - | _ | - | 21 | 23 | 32 | | 1 |
| 6 | 7.4 | ρψ | ۰ - | - c | - 0 | ņ | , | | י מ | | _ | - | - | 24 | 27 | 8 | | ' |
| 8 | | - | 21 | ? | ? | ņ | - | 4 | _ | - | - | - | - | 2 | R | 32 | | • |
| 3 1 | 4 . | ` | F | ņ | က္ | -18 | - | 2 | - | - | - | - | - | 22 | 24 | ¥ | | |
| 9 | 3.5 | | 6- | 9 | -4 | -18 | - | 2 | 2 | 8 | _ | - | - | 2 | i S | : 6 | | ' |
| 8 | 3.0 | 4 | -5 | 4 | - | -21 | | ۳. | ď | - | - | - | - | Ş | 3 5 | 3 8 | | 1 |
| 20 | 2.5 | κ̈́ | တု | τ'n | 5- | -17 | - |) et | o | - c | با - | _ u | -, | <u>n</u> c | 2 6 | 35 | | ٠ |
| 40 | 2.0 | ې | ¥F* | - | - | - 2 | | , | , | , | , | | - | 53 | 53 | 35 | | ' |
| 5 | | ۰ ۲ | | - 1 | - , | 7 7 | - 1 | _ | + | _ | - | _ | - | ន | 23 | 8 | | • |
| 9 | 5 | <i>.</i> | /- | , | - | -51 | -7 | 9 | 9 | 9 | ۲- | -7 | -2 | 8 | 33 | 98 | | |
| ₹ : | 0.5 | - | Ŗ | - | - | -21 | - | o | - | - | - | _ | - | ę | 90 | 200 | | 1 |
| 9 | 0.5 | Ķ | 77 | - | - | -40 | -21 | - | • | - | <u>ن</u> | . 5. | ۶. | 2 | 3 F | h c | | 1 |
| • | ć | | | | - | | | | | | i | 1 | . , | ٥ | | 92 | | • |

Note: Bold Values Exceed Test Regiurements

Table 2A (cont.)
Enmet

| .48% CO2 | 202 | Short Term Test | rm Test | | | | Long Term Test | 1 Test | | | | | | | | | | |
|----------|----------|-----------------|----------|------------|------------|----------------|----------------|----------|----------|----------|----------|----------|----------|--|---------------------------------|---------|-----------------|---------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 Week 13 | Week 13 |
| Stec | Expected | 01/09/95 | 01/18/95 | 01/27/95 | 02/03/95 | 02/09/95 | 02/16/95 | 02/24/95 | 03/02/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/06/95 | 04/13/95 | | | ٠, |
| 0 | 00:00 | | | Calibrated | Calibrated | Calibrated | | | | | | | | | | | , | , |
| 10 | 0.25 | | | 16 | -20 | -20 | -50 | 50 | 0 | - 60 | 50 | -50 | 20 | 100 | 100 | 220 | | |
| 20 | 0.50 | | | -20 | -20 | -50 | -20 | 0 | 0 | 40 | c | -20 | c | 09 | 69 | 140 | | |
| 30 | 0.75 | • | | 0 | -7 | ģ | -7 | 7 | · - | 8 | -50 | | . ^ | 8 | 47 | 87 | , | |
| 40 | 1.00 | | | 0 | -10 | -50 | -10 | 0 | 0 | 200 | c | 0 | c | 97 | 97 | 90 | | |
| 20 | 1.25 | | • | -12 | 4 | 50 | -12 | 12 | 4 | 28 | 4 | 4 | 4 | 28 | 4 | 09 | , | |
| 09 | 1.50 | | | 0 | -7- | -13 | 7: | 7 | 7 | 13 | 7 | -7 | o | 33 | 33 | 09 | | |
| 2 | 1.75 | ٠ | | ō, | ō, | -14 | ę | ო | m | 4 | m | ņ | m | 8 | 3.5 | 99 | | • |
| 80 | 2.00 | | | 0 | -5- | -10 | 0 | 5 | 2 | 10 | 0 | 0 | c | S | 30 | 20 | | Ι. |
| 6 | 2.25 | | • | 8 | -7 | - | 2 | 7 | 7 | 16 | 0 | Ġ | | 24 | 8 | . 55 | , | • |
| 5 | 2.50 | | | 4 | 4 | æ | 0 | 8 | 4 | 20 | 4 | 0 | 4 | 24 | 28 | 44 | | |
| 06 | 2.25 | | | .7 | -2 | ÷ | Ņ | 7 | 7 | = | 8 | ç | 7 | 24 | 8 | ž. | , | |
| 80 | 2.00 | • | | 0 | ç | - 1 | 0 | 5 | 0 | 10 | 0 | 0 | 0 | 88 | 8 | 20 | | , |
| 2 | 1.75 | | | ဗှ | op. | Ģ. | ငှ | 6 | ო | က | ო | ဗု | m | 8 | E | 9 | , | |
| 9 | 1.50 | | | -7- | -7 | -7 | -7 | | 0 | 7 | 0 | 0 | 0 | S | 33 | 9 | | - |
| 20 | 1.25 | | | 93, | 4 | -50 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 8 | 1 | 09 | • | |
| 4 | 1.00 | | | -10 | 0 | -50 | -10 | 10 | 0 | 0 | 0 | 0 | 0 | 8 | 40 | 70 | ļ. | , |
| 30 | 0.75 | | | -7 | -7 | 8 | -50 | 7 | 7 | 50 | -7- | | ! | × | 47 | 87 | | |
| 8 | 0.50 | | | 8. | -20 | -20 | -20 | 0 | 0 | 0 | 0 | -20 | 0 | 64 | 8 | 8 | | |
| 우 | 0.25 | | | ş | 25 | 9 | 50 | 50 | 0 | 0 | 20 | -50 | 20 | 28 | 100 | 180 | , | , |
| c | 000 | | | | | | | | | | | | | The second secon | CONTROL CONTROL CONTROL CONTROL | | | _ |

Table 2B RKI Short-term and Long-term Testing

| | | 14,500 | Week 13 | 06/22/95 | | ğ | 21 | - 4 | 19 | 16 | - | | 2 | 5 | 9 | 10 | 2 | 1 | ų. | 2 | 6 | 21 | 53 |
|---|-----------------|---------|-----------|-------------|------------|----|-----|-----|-----|------|-----|----------|-----|-----|------|-----|------------|-----|-----|-----|-----|-----|-----|
| , | | Mank 40 | Week 12 | 06/14/95 | | 24 | 14 | | 7 | = | 5 | 2 0 | 0 | 7 | 7 | 7 | œ | Ç | | = : | 12 | 14 | 24 |
| | | Mook 11 | AAGGV - | 06/06/95 | | 24 | ē | : ; | 4 | 13 | Ξ | a | ָ | 80 | 80 | 60 | 6 | Ţ. | 13 | 2 : | 14 | 19 | 24 |
| | | Mook 10 | 2004 | 05/30/95 | | ส | -61 | , , | - | 5 | 5 | Ξ | = ! | 10 | 10 | 5 | Ξ | 13 | £ | 2 ! | - | 5 | 23 |
| | | Wook 0 | C VOOL | 05/24/95 | | 54 | 14 | ç | 2 | 9 | o | ď | | و | 9 | 9 | 9 | o | F | 2 (| 2 | 14 | 19 |
| | | Wook 8 | | 05/19/95 | | 24 | 14 | ÷ | 3 | ₽ | თ | ď | • | ٥ | 9 | 9 | 9 | 6 | 10 | : | 21 | 4 | 24 |
| | | Week 7 | | 05/11/95 | | 14 | 9 | ď | | ιΩ | 4 | ٩ | 1 (| 2 | CI | 9 | Q | 4 | 2 | | 0 | 9 | 4 |
| | | Week 6 | | 05/04/95 | | 6 | 9 | Œ | | 80 | 9 | c | | c | ო | 5 | S | 9 | 9 | ď | ٠ | 9 | თ |
| | | Week 5 | | 04/28/95 | | 4 | - | - | | n | - | - | | | 0 | 0 | - | - | ო | | | - | 4 |
| | | Week 4 | 100000 | 04/20/85 | | 4 | 4 | ^ | | מי | 2 | - | | | 0 | ٥ | - | - | ო | 0 | | 4 | 4 |
| | ו Test | Week 3 | 1000 | C8/51/45 | (| 6 | 9 | ဖ | , | ٥ | 4 | 4 | ď | , | N · | 8 | 4 | 4 | ဖ | œ | | : م | 4 |
| | Long Term Test | Week 2 | 24 POR ME | 28.00 | , | 4 | - | | , | יכ | ٥ | 0 | - | , | י קי | 2 | - | - | - | - | - | _ , | - |
| | | Week 1 | 19/30/02 | Colonia de | Caribrated | • | - | - | | | _ | - | c | , | | 0 | 0 | 0 | - | - | - | | 4 |
| | | Week 4 | 03/20/85 | Collibrated | Calibrated | | - | - | | - (| -5. | - | ç | , | 'n | 7 0 | 5 (| 9 | 0 | | - | | 4 |
| | | Week 3 | 03/15/95 | Callbradod | - A | | _ | • | ç | 4 6 | ? | ņ | ņ | · | ņ• | | † (| ? | Ņ | 4 | 4 | ۰, | - |
| | m Test | Week 2 | 03/08/95 | Callbrated | V | , | | - | ٠. | , , | - | - | 0 | c | | | - • | - , | , o | _ | _ | | 1 |
| | Short Term Test | Week 1 | 02/27/95 | Calibrated | 4 | | 4 (| و | c | 9 (4 | 0 | 4 | വ | Ľ | ייי | נו | , c | | ۰ | 9 | 4 | • • | t |
| | , , | | Expected | 0.0 | 9 | | 0 0 | 3.0 | 4.0 | | 5 | <i>i</i> | 7.1 | - a | | | - + | 5 | | 3.0 | 2.0 | i | 0 |
| | 10.1% CO2 | , | Stec | 0 | 10 | ç | 2 6 | 3 | 40 | ç | 8 8 | 8 1 | 5 | 80 | 2 5 | 8 | 8 6 | 8 | ? 6 | 3 | 8 | £ | ? 0 |
| | | | | | | | | | | | | | | | | | | | | | | | |

| | c |
|--|---|
| | Č |
| | Č |
| | Ū |
| | è |
| | è |
| | Ц |
| | |

| | Wook 11 Wook 12 Wook 13 | NOON II | 06/06/95 06/14/95 06/22/95 | , | 50 | SS | 17 | 15 | 16 | 13 | 13 | 13 | Ξ | 13 11 15 | = | 13 | 13 | 13 | 16 | 15 | 17 | 25 |
|-----------------------|-------------------------|-------------------|----------------------------|-----|------|------------|----|--------|-----|------|----------|----------------|-----|------------|-----|------|-----|-----|-----|----------------|-----|------------|
| | Week 9 Week 10 | | 05/24/95 05/30/95 | | | | | | | | | | | 11 15 | | | | | | | i | |
| | 7 Week 8 | | | · v | P. C | 5 5 | 18 | 14 | 15 | 12 | 12 | 12 | 10 | 10 | 10 | 10 | 12 | 12 | 15 | 14 | 19 | 24 |
| | Week 6 Week 7 | | | | | | | о О | İ | | 8 | | 7 6 | 9 2 | | 2 8 | 8 | 7 7 | | 7 9 | | 14 14 |
| | Week 5 | | | 10 | | † c | 2 | 2 . | 8 | თ (| 6 | თ - | 6 | ∾ . | 4 | ო (| 80 | თ , | | α : | 6 | 4 |
| | Week 3 Week 4 | 04/13/95 04/20/05 | | 6 | | t - | 2 | 4 (| 20 | | 3 | 4 . | 4 | e . | 4 | 4.0 | 2 | | 2 | 4 . | 3 | 4 ; |
| | Week 2 W | 04/06/95 | | σ | 4 | ٠. | | | - - | - 0 | 7 | Ν, | | , , | - | Ν + | - - | - • | | | | _ |
| | Week 1 | 03/30/95 | Calibrated | 6 | 4 | | , | V T | | - « | 2 | ימ | - | N T | - 6 | N C | , | - • | - | N T | - | 4 ; |
| | Week 4 | 03/20/95 | Calibrated | 19 | 4 | | | v + | | - c | V | N • | - , | - • | - | N C | 7 | - • | - - | - • | - - | - (|
| | Week 3 | 03/15/95 | Callbrated | 61 | 4 | - | - | - • | - - | ، - | , | 'nc | , | 'n | 3 0 | 'nς | 4 | ţ | ٥ | ۹۶ | , | ρ, |
| | Week 2 | 03/08/95 | Calibrated | 19 | 4 | _ | , | 4 + | - | - r | | o - | | - + | - - | N O | - | | - - | | | - 0 |
| | Week 1 | 02/27/95 | Calibrated | 6 | - | - | - | | - | | - - | , c | | - c | | > + | | | - | | | t (|
| ZOZ. | i | Expected | 0.0 | 0.5 | 0.1 | 1.5 | 20 | 2 10 | 3.0 | . e. | 200 | . 4 | 0 | 5.4 | 0.4 | 9 10 | 30 | 2.5 | 0.0 | , , | 0. | 2 4 |
| 3.54% CC S. 54% | i | Stec | 0 | ٤ | 8 | 30 | 40 | 202 | 8 | 8 8 | æ | 8 8 | ٤ | 8 | 2 | 8 8 | 9 | 20 | 8 | 2 8 | 8 | 3 5 |

Note: Bold Values Exceed Test Regiurements

Table 2B (cont.) RKI

| ŗ |
|-------|
| Error |
| cent |
| Per |
| ative |
| Re |

| 2.48% CO2 | 705 | Short Term Test | m Test | | | | Long Term Test | ו Test | | | | | | | | | | |
|-----------|----------|-----------------|------------|------------|------------|------------|----------------|----------|------------|----------|----------|----------|----------|----------|---------|----------|----------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/06/95 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/19/95 | 05/24/95 | , | 06/06/95 | 06/14/95 | 06/22/95 |
| 0 | 0.00 | Calibrated | Calibrated | Calibrated | Calibrated | Calibrated | | | | | | | | | | | | |
| 10 | 0.25 | 41 | 41 | 41 | 41 | 41 | 41 | 41 | 59 | 4 | 19 | 81 | 122 | 101 | 121 | 121 | 101 | 13 |
| 20 | 0:20 | 11 | 15 | F | - | 21 | 21 | 21 | 31 | 21 | 31 | 4 | 19 | 51 | 74 | 61 | 51 | 44 |
| 30 | 0.75 | 8 | - | 80 | - | 80 | 80 | 80 | 2 | 80 | 21 | 28 | 34 | ä | 41 | ₩. | ¥ | 8 |
| 40 | 1.00 | | - | - | ę. | 9 | 9 | 9 | 16 | 9 | 16 | 21 | 26 | 26 | 36 | 31 | 26 | 15 |
| 20 | 1.25 | - | ۴. | ကု | Ŧ | - | - | - | 6 | - | o | 17 | 21 | 50 | 8 | 54 | 20 | 12 |
| 09 | 1.50 | £- | ဇှ | ę. | -13 | - | - | - | 60 | - | 80 | 14 | 21 | 20 | 27 | 50 | 17 | 14 |
| 20 | 1.75 | -5 | -5 | -5 | -11 | - | - | 4 | 7 | - | 6 | 12 | 2 | 18 | 56 | 20 | 18 | o |
| 80 | 2.00 | 4- | 4 | 4- | 6- | - | ဗ | ၈ | 80 | က | ۵ | 13 | 16 | 15 | 26 | 18 | 15 | 10 |
| 06 | 2.25 | 4- | ÷ | 4- | -8 | 3 | 3 | 3 | 8 | က | 80 | 12 | 19 | 91 | 23 | 18 | 14 | 12 |
| 9 | 2.50 | ņ | ÷ | ဗှ | -7 | - | က | е | 6 | 1 | 6 | 11 | 17 | 16 | 22 | 18 | 16 | 10 |
| 06 | 2.25 | - | 4 | -4 | -10 | - | က | က | c o | က | œ | 12 | 19 | 16 | 23 | 18 | 16 | 12 |
| 80 | 2.00 | _ | 4 | -4 | -12 | 1 | - | 3 | 80 | က | œ | 13 | 16 | 15 | 26 | 20 | 15 | 10 |
| 20 | 1.75 | -5 | 5- | -5 | -16 | - | - | 4 | 7 | 4 | 7 | 6 | 21 | 6 | 26 | 50 | 18 | 6 |
| 9 | 1.50 | ဗှ | φ | 9- | -16 | 1 | - | - | 8 | - | 80 | 14 | 21 | 17 | 27 | ೪ | 17 | 5 |
| 20 | 1.25 | + | -7 | -3 | 6. | _ | | - | 6 | - | o | 17 | 21 | 20 | 83 | 24 | 8 | 12 |
| 40 | 1.00 | 1 | 6- | -4 | -24 | 1 | 9 | 9 | = | 9 | 16 | 16 | 26 | 26 | 36 | 26 | 26 | 15 |
| 99 | 0.75 | œ | 9- | - | -26 | 8 | 8 | 8 | 21 | 80 | 21 | 21 | 34 | Ŋ | 41 | 41 | 3 | 50 |
| 50 | 0.50 | = | - | : | -29 | -1 | F | 21 | 31 | 21 | 31 | 41 | 51 | 51 | 7.4 | 61 | 51 | 41 |
| 10 | 0.25 | 41 | - | 23 | -100 | -61 | 7 | 41 | 59 | # | 61 | 81 | 102 | 101 | 121 | 121 | 101 | 18 |
| 0 | 0.00 | | | | | | | | | | | | | | | | | |

| 2 |
|---|
| 0 |
| Ç |
| v |
| 8 |
| ಸ |

| | 7000 | Wook 1 | Wook 2 | Wook 3 | Wook 4 | Wook 1 | Wook o | Wook 3 | Wook 4 | Mook 5 | Mook | Mook 7 | Monto | Mook | Mook 10 | Mook 11 | Mook 40 | Mock 40 |
|-----|----------|------------|------------|------------|------------|------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| | | | 1 | | - | 2001 | 7 400 F | 200 | 1 | 200 | 0 4004 | 2004 | 0 400 | e voor | Aces 10 | A AGGA | MAGE IZ | 2 4004 |
| ပ္မ | Expected | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/06/95 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/19/95 | 05/24/95 | 05/30/95 | 26/90/90 | 06/14/95 | 06/22/95 |
| _ | 0.000 | Calibrated | Calibrated | Calibrated | Calibrated | Calibrated | | | | | | | | | | | | |
| 0 | 0.025 | 99: | 92 | -18 | 92 | £\$ | 92 | 477 | 477 | 92 | 477 | 699 | 1246 | 1246 | 1246 | 1054 | 699 | 862 |
| 0 | 0.050 | 4 | 92 | 4 | 92 | 188 | 92 | 188 | 285 | 92 | 285 | 381 | 573 | 573 | 573 | 477 | 381 | 477 |
| 0 | 0.075 | 28 | 28 | 28 | 28 | 156 | 28 | 156 | 221 | 92 | 221 | 285 | 413 | 413 | 413 | 349 | 285 | 285 |
| ٥ | 0.100 | 4- | 44 | 4- | 44 | 92 | 92 | 140 | 188 | 44 | 188 | 237 | 285 | 285 | 285 | 285 | 188 | 237 |
| 0 | 0.125 | 15 | 15 | 15 | 54 | 92 | Z | 35 | 131 | 2 | 131 | 169 | 246 | 246 | 246 | 208 | 169 | 169 |
| 0 | 0.150 | 28 | 28 | 4- | 28 | 99 | - 99 | 92 | 124 | - 60 | 124 | 156 | 221 | 221 | 221 | 188 | 156 | 156 |
| 0 | 0.175 | 10 | 10 | 10 | 10 | 65 | - 65 | 92 | 92 | 37 | 35 | 120 | 175 | 175 | 175 | 147 | 120 | 120 |
| 0 | 0.200 | 4- | 20 | 4- | 20 | 44 | - 88 | 89 | 92 | 44 | 92 | 116 | 164 | 140 | 191 | 140 | 116 | 116 |
| 0 | 0.225 | 7 | 28 | 7 | 7 | 20 | 50 | 71 | 71 | 50 | 7 | 114 | 135 | 135 | 135 | 114 | 85 | 114 |
| 8 | 0.250 | 7- | 15 | 4- | 15 | 38 | 54 | 54 | 73 | 35 | 23 | 92 | 112 | 112 | 112 | 112 | 85 | 92 |
| ٥ | 0.225 | 7 | 28 | -15 | 28 | 20 | 71 | 71 | 71 | 50 | 71 | 114 | 136 | 135 | 135 | 114 | 35 | 114 |
| | 0.200 | 4- | 20 | 4- | 20 | ŧΦ | 68 | 68 | 92 | 4 | 35 | 116 | 140 | 140 | 164 | 140 | 116 | 116 |
| 0 | 0.175 | 10 | 37 | 10 | 37 | 37 | 92 | 92 | 92 | 37 | 92 | 120 | 175 | 175 | 175 | 147 | 120 | 120 |
| 0 | 0.150 | 4- | 28 | 4- | 28 | 28 | 124 | 65 | 124 | - 09 | 124 | 156 | 188 | 188 | 221 | 188 | 156 | 156 |
| 0 | 0.125 | 15 | 54 | -23 | 54 | 54 | 131 | 131 | 131 | 54 | 131 | 169 | 208 | 208 | 246 | 208 | 169 | 169 |
| 0 | 0.100 | 4. | 44 | 4- | 44 | 44 | 188 | 140 | 188 | 92 | 188 | 188 | 285 | 285 | 285 | 285 | 188 | 237 |
| 0 | 0.075 | 28 | 92 | -36 | 92 | 28 | 221 | 233 | 221 | 92 | 221 | 285 | 349 | 349 | 349 | 349 | 285 | 285 |
| 0 | 0.050 | 4- | 92 | 91- | 35 | 4- | 285 | 188 | 285 | 92 | 285 | 381 | 573 | 477 | 573 | 477 | 381 | 381 |
| 0 | 0.025 | -100 | 92 | -100 | 92 | -100 | 477 | 477 | 477 | 92 | 477 | 699 | 1054 | 862 | 1054 | 1054 | 699 | 699 |
| _ | 0.000 | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | |

Table 2C Nova Short-term and Long-term Testing

| | | Week 13 | 05/04/95 | | Ş | 2 8 | Ņ | 2 | -18 | , t | 2 ; | - | -1 | -10 | 6 | + | -14 | 1. | 2 6 | 75. | -50 | -10 |
|-----------------|----------|----------|-----------|------------|------|-----|----------|-----|----------|-----|--------|-----|-----|----------------|--------------|-----------------|-----|------|------|--------|----------|-----|
| , | | Week 12 | 04/28/95 | | Ç | 2 | <u>.</u> | -17 | -13 | 5 | 4 5 | ? | 8- | -7- | φ | -10 | -14 | -15 | 1. | | 0 | 우 |
| | | Week 11 | 04/20/95 | | c | ٤ | 2 : | -13 | -2 | αŗ | 0 | P | 6- | 4 | ņ | ń | φ | 7- | - 5- | 2 | <u>.</u> | 0 |
| | | Week 10 | 04/12/95 | | Ç. | 2 6 | 2 : | -50 | ÷ | 45 | ç | 2 | ÷ | ÷ | - | -13 | -16 | -18 | 6. | 2 2 | 72- | 9- |
| | 0.1741 | Week 9 | 04/05/95 | | c | 5 | 2 : | -10 | -7 | 4- | 9 | ? . | ٥ | 0 | 0 | -5 | 4- | -2 | -10 | Ş | 2 . | 0 |
| | Michigan | Meek 0 | 03/30/95 | | c | 4 | 2 5 | 2 | 우 | -10 | -7 | | 4 | 4 | 4- | -7 | -10 | -10 | .13 | ٤ | 2 , | 0 |
| | Mocky | MAGE | 03/20/95 | | 0 | -10 | 2 5 | 01- | က် | 4 | ç | , ۱ | ٥ | 0 | - | 0 | 4 | ι'n | -10 | ç | ? (| 0 |
| | Mooke | 2000 | 03/16/95 | | 0 | -10 | ÷ | 2 | -7 | φ | ę | , , | - | Ţ | ę- | က္ | မှ | -2 | -10 | -1 | ? . | > |
| | Wook 5 | CVD | 03/08/95 | | 9 | -15 | 7 | - | -15 | -16 | £- | : : | - | ÷ | Ŧ | - 13 | -14 | -18 | -50 | -20 | ; | 2 |
| is . | Wook 4 | | 03/02/95 | | 0 | 9- | | 2 | - | 8- | ιŲ | | 7 | ψ | -10 | က် (| æ, | -2 | -10 | -10 | | > |
| m Teet | Wank 3 | | 02/24/95 | | 0 | -15 | <u>e</u> | | <u>-</u> | -10 | -2 | q | , | ÷. | ۹ | - ; | 2 | -10 | -13 | -15 | c | • |
| l ond Term Test | Week 2 | | 02/15/95 | | 10 | -1 | ٠. | 2 | ņ · | ? | ņ | | | . | - | o ' | 4 . | ņ | -7- | ċ | ç | ? |
| | Week 1 | | 02/10/85 | Calibrated | ٥ | ç | 9 | | ? . | 4- | ņ | ٠. | | , , | - , | Ņ | , | ŗ. | ٩- | 우 | c |) |
| | Week 4 | 10000 | 02/03/85 | Calibrated | ٥ | လု | -10 | 4 | , . | 4- | ĊΊ | 0 | | , « | , | Ņ | , | ဂု ၊ | ·- | 우- | c | • |
| | Week 3 | 20100 | 0112/1/33 | Calibrated | ٥ | 우 | 우 | ų | , • | 4- | ကု | - | - | | | ¥ 5 | | · ; | 2 | ę | 0 | |
| rm Test | Week 2 | 01/18/05 | 200 | Calibrated | 2 | ι'n | -7 | 4 | | , | > | 0 | 6 | | | ې د | 19 | , | ? | ι'n | 우 | |
| Short Term Test | Week 1 | 01/09/05 | College | Calibrated | ا اح | ဂု | 6- | c | | | N | က | ٥ | 1 (* | 0 | | c | ۰, | ? | ņ | 2 | |
| 202 | | Expected | | 9 6 | 2 3 | O ! | 3.0 | 4.0 | 4 | | - 0 | 7.1 | 8.1 | 7 | | , in | 4.0 | 9 6 | 0.0 | o, | 0. | 0.0 |
| 10.1% CO2 | | Stec | c | , ç | 2 8 | 3 3 | 8 | 9 | 05 | 86 | 8 1 | 5 | 80 | 1 2 | ç | 20 | 40 | £ | 3 8 | S N | 9 | 0 |

| | | > | |
|-------|----------------------------|--------------------|--|
| | | Week 7 | |
| | | eek5 Week6 Week7 V | |
| | | Week 5 | |
| | | Week 4 | |
| | | Week 3 | |
| | 0 1 - 744 | Week Z | |
| | 1. 4 14/2 als 4 14/2 als 0 | MARK I | |
| | Wook 4 | MAGEN 4 | |
| | Wook 2 | 2 4004 | |
| | Wook 2 | 7 | |
| | Week 1 | 2001 | |
| 6 CO2 | | Eventual Park | |
| 5.04% | | 0000 | |
| | | 2 | |

| | Wook 13 | 2004 | 05/04/95 | | -21 | - | -21 | -16 | -5- | -21 | Ψ. | 1 | 2 \$ | - | -13 | -16 | -18 | -18 | -21 | -21 | .5. | 1 7 | • | - | <u>-</u> |
|--------|---------|----------|------------|----------|-----|----------------|-----|--------------|-----|----------|-----|-----|----------|-----|------------|-----|------------|--------|----------|----------|------------|------------|----------|-----|----------|
| | Week 12 | | 04/28/95 | į | -51 | ÷ | -14 | -16 | -21 | -17 | -18 | E- | 5 5 | 3 | ÷ | -12 | -13 | -15 | -17 | -17 | -16 | -14 | | ÷ | -21 |
| | Week 11 | | 04/20/95 | • | - | ÷ | -7 | -16 | -17 | -14 | -12 | ÷ | ۲. | | rὑ | -7 | -11 | -12 | -14 | -17 | | 4- | | | - |
| | Week 10 | | 04/12/95 | , | - | - | -7 | -11 | -13 | -11 | ģ | œ | ιĶ | | ņ | -3 | φ | 6- | ÷ | -13 | ÷ | -7 | | - , | - |
| | Week 9 | 1000 | 04/05/95 | č | 17- | - | -7 | -16 | -17 | -14 | -12 | ÷ | -10 | | ָרָה יִי | -1 | ÷ | -12 | -14 | -17 | ÷ | -7 | | - , | - |
| | Week 8 | 10000 | 68/15/50 | , | | _ | -14 | -16 | -13 | -14 | -12 | φ | -7 | | ဂု : | 9 | ÷ | -12 | -14 | -13 | -16 | -14 | - | - • | - |
| | Week 7 | 900000 | 080700 | | - | _ | -7 | ÷ | -13 | <u>+</u> | -12 | æ | ۲- | 4 | ဂု ၊ | -/- | φ | ė. | -14 | -13 | ÷ | -7 | - | - • | - |
| | Week 6 | 03/15/05 | 200 | | - , | - | | - | -13 | ÷ | 6- | φ | ċ | ç | יי | ç | φ | ρ. | F | -13 | - | -2 | - | | - |
| | Week 5 | 03/08/05 | | - | | _ | -, | 91- | -17 | -17 | -15 | -13 | -12 | -11 | - 5 | 01: | -13 | 2 | /I- | <u>-</u> | -16 | -14 | - | | - |
| | Week 4 | 03/02/95 | | - | | - 1 | , | ŗ; | -13 | -14 | 6- | ÷ | -7 | ιç | , Ş | 2 ; | - • | ָרָק. | <u>,</u> | 51: | F | -7 | - | - | • |
| | Week 3 | 02/24/95 | | * | - | - ; | 4 | 9 9 | 2 | 4. | -12 | F | -10 | o, | , <u>c</u> | 2 | - 5 | 71: | 4 1 | - | ٠ - | <i>-</i> - | - | - | |
| | Week 2 | 02/15/95 | | - | - | - , | - ; | | ויף | - • | ۾ | ņ | ç | - | | - - | ρ¢ | 1 9 | ٠, ٥ | | <u>-</u> 1 | , | თ | - | |
| | Week 1 | 02/10/95 | Calibrated | - | | - 1 | | - 0 | 21- | | 9 | φ | ç- -2 | က္ | ιç | | ρc | ? - | - 5 | 2 | P 1 | , | - | - | |
| 1 | Week 4 | 02/03/95 | Calibrated | - | - | | - 4 | PC | 1 | • | + | ņ. | - | _ | - | | 7 | 1 | ٠ ٩ | 9 4 | ρ, | - | - | - | |
| Minels | Week 3 | 01/26/95 | Calibrated | 5 | o. | · - | - 4 | pq | , | • | , | - , | _ | - | - | - | - 7 | 7 | ŗų | ۹ | ρ, | - , | თ | 19 | |
| Mook | Z YAAAA | 01/18/95 | Calibrated | - 19 | 6 | • | - q | γų | , | ٠ ۵ | | ņ, | - | - | - | ۳٫ | φ | , | ۰ ۹ | ٩ | ٠. | - | თ | 19 | |
| Wook 4 | Vac. | 01/09/95 | Calibrated | - | _ | , | ۽ ا | οφ | , | ٠ ۲ | , | ۰ ب | - | - | - | ę | 4- | 7. | ۰ م | به | ۰. | - | ກ | - | |
| | | Expected | 0:0 | 0.5 | 0.0 | 7. | 000 | 2 2 | 0 | | |) L | 0 | 0.0 | 5.4 | 4.0 | 6 | 3.0 | 2.5 | 20 | 4 | 1 | <u> </u> | 0.5 | 0:0 |
| , | Ī | Stec | 0 | 9 | ଷ | 30 | 40 | 20. | S S | 1 8 | 2 | 8 8 | 8 | 3 | 06 | 80 | 2 | 09 | 20 | 40 | 9 | 3 8 | 2 | 9 | 0 |

Note: Bold Values Exceed Test Reglurements

Table 2C (cont.)

| 2.48% CO2 | C02 | Short Term Test | m Test | | | _ | Long Term Test | n Test | | | | | | | | | | |
|-----------------|----------|-----------------|----------|------------|------------|------------|----------------|----------|----------|----------|----------|--------------|----------|--------|---------|------------------|----------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 01/09/95 | 01/18/95 | 01/27/95 | 02/03/95 | 02/09/95 | 02/16/95 | 02/24/95 | 03/02/95 | 03/06/95 | 03/15/95 | 03/20/95 | 03/30/95 | | | 04/20/95 | O4/28/95 | ĎS/M4/95 |
| 0 | 0.0 | | | Calibrated | Calibrated | Calibrated | | | | | | | | | | | 200 | |
| 우 | 0.3 | | • | 20 | 20 | -50 | -50 | -80 | 95- | 03. | .En | .An | 180 | 03. | ug. | O. | | 44 |
| 80 | 0.5 | | | 40 | 40 | 0 | 0 | С | c | 30 | 3 | 3 | 6 | 3 | 06- | 5 | 2 | 8 |
| 30 | 0.8 | | | 33 | 33 | 7 | 7 | ۲- | 2 | ۰, | ^ | | ۲. | , , | 3 1, | 3 4 | 2 5 | 2 7 |
| 9 | 0. | | | 20 | 20 | 0 | 0 | 0 | 0 | 0 | 0 | -10 | 0 | | 0 | c | 100 | -10 |
| 20 | 1.3 | • | | 12 | 12 | 4 | 4 | -12 | -12 | -12 | -12 | 2 | 2 | -12 | 4 | . . . | 27- | ÷ ÷ |
| 9 i | r. | | ı | 7 | 7 | -7 | 2- | -2 | -13 | -13 | -2 | -13 | -7- | -13 | -2- | -13 | -13 | -50 |
| 9 | 20 | 1 | • | ၈ | 6 | 6- | 6 | -14 | -14 | -14 | -14 | 4- | -14 | -14 | -14 | -14 | -50 | 200 |
| 8 8 | 2.0 | | | ις: | 0 | -10 | -10 | -15 | -15 | -20 | -15 | -15 | -15 | -15 | -15 | -15 | Ş. | -50 |
| 3 | 5.3 | | • | 2 | 2 | Ŧ | F | -16 | -16 | -16 | -16 | -16 | -16 | -16 | Ŧ | -16 | -16 | -50 |
| 2 8 | 5, 6 | | • | 4 | 0 | -12 | -12 | -16 | -12 | -16 | -16 | -16 | -16 | -16 | -12 | -16 | -20 | -50 |
| 3 | 23 | • | | 2 | 2 | +- | = | -16 | -16 | -16 | -16 | -16 | -16 | -16 | ÷ | -16 | -50 | 20 |
| 2 6 | 0.5 | • | | un (| 0 | 우. | 9 | -15 | -15 | -15 | -15 | -15 | -15 | -15 | -15 | -15 | -20 | -20 |
| 2 8 | 0, 4 | • | • | | 3 | 6- | 6- | -14 | -14 | -14 | -14 | -14 | -14 | -14 | -14 | -14 | -20 | 4- |
| 8 8 | | | • | 7 | ij. | | | -7 | -7 | -13 | -2 | . | -7 | -13 | -2 | -13 | -13 | -50 |
| S S | 2 | | • | 12 | 12 | -4 | 4 | -12 | 4 | 4 | -4 | -4 | -12 | -12 | 4 | -12 | -12 | -12 |
| \$ 8 | 0.0 | | • | 2 | 20 | 0 | 0 | 9- | 0 | 0 | 0 | 0 | 0 | 0 | 0 | -10 | <u>-</u> | -20 |
| 8 | 83 | • | • | 3 | 83 | , | _ | | 7 | -7 | -2 | -7 | -7 | .7 | | .7 | -50 | -50 |
| Q (| 0.5 | | • | \$ | 49 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | -50 | -20 | -20 |
| 2 c | e 0 | | | 09 | 09 | -50 | Ŗ | 9- | | 8 | 9 | 9- | 9- | 99- | 09- | -60 | , 5 | -90 |

Table 2D GeoL Short-term and Long-term Testing

| | | _ | | _ | | _ | _ | _ | _ | | , | _ | | _ | | _ | _ | | _ | | _ | _ | | |
|---|-----------------|---------|----------|------------|------------|--------|-----|-----|-----|-----|-----|-----|-----|--------------|------------|---|---------|-----|-----|-----|-----|-----|------|-----|
| | | Week 13 | 2 3000 | CRANNON | ć | 0 | - | - | - | - • | - | 0 | c | | ۰ د | 0 | ç | ٠, | - | - 1 | 0 | - | - • | _ |
| | | Week 12 | 50000 | CRIOCICO | • | - | - | o | - | - , | - | > | - | , | u , | - | - | | | י כ | - | - | - د | > |
| | | Week 11 | 05/04/06 | 00144100 | c | | _ | - | - | - • | - | N | 'n | ď | . | ٥ | m | c | , | - (| 5 | - | . د | > |
| | | Week 10 | 05/16/05 | 26.00 | c | , | 0 | Ņ | - | - c | | > | _ | - | | _ | 0 | • | - - | - 0 | ۶, | - | ، د | Ņ |
| | | Week 9 | 05/11/05 | 200 | 7 | - | 5 | ņ | - | . • | | - | - | - | - (| - | ÷ | ٠, | c | ŅC | ? | 0 | , 6, | , |
| | | Week 8 | 0500405 | | * | , | > | ņ | _ | | - - | _ | - | c | | 0 | - | - | - 0 | ų . | - | 0 | • | - |
| | | Week 7 | 04/28/95 | Callbrated | CallDlated | 1 | > | ņ | - | | | - | - | ٥ | 1 - | | - | ۳. | 7 | - c | , | - | 9 | 1 |
| | | Week 6 | 04/20/05 | | 4 | | Ņ | ကု | -5 | י ק | 7 0 | ? | - | - | ٠ , | 2 | ကု | 7- | ۲, | 9 | 2 | ကု | 4- | |
| | | Week 5 | 04/13/95 | | ç | , | _ | ဇှ | 6- | 4 | c | ? | ç- | ç | , 4 | , | 4 | 4 | 4- | , | | ç | ę | , |
| ŕ | | Week 4 | 04/05/95 | | ď | , | - | ç. | က္ | ď | ۹ | 1 | 0 | - | ، م | , | çŅ | ċ | , e | ۲, | , | Ņ | 4 | |
| | m Test | Week 3 | 03/30/95 | | ç | - | - | ဇှ | ņ | ņ | | 4 | -5 | -5 | ď | | ņ | ů | 4- | 4 | - | Ņ | ကု | |
| | Long Term Test | Week 2 | 03/20/95 | | ç | 9 | 7 | 4- | 4 | 4. | ۲ | ۰ د | -5 | 0 | - | | ņ | ņ | 4- | Ψ- | | 4 | φ | |
| | | Week 1 | 03/15/95 | Calibrated | ကု | - | . (| ? | ဇှ | ņ | ç | | - | - | ď | , | ? | က္ | 6- | 4 | | Ņ | 2 | |
| | | Week 4 | 03/08/95 | Calibrated | က္ | - | - (| ? | ကု | ? | ç | | 5 | ņ | ç | | - | ကု | ဇှ | ņ | | - | ņ | |
| • | | Week 3 | 02/27/95 | Calibrated | ú | - | . (| 7- | Ņ | ကု | 6- | | - | 0 | ú | , | ? | ကု | ငှ | ę, | - | - | က္ | |
| | rm Test | Week 2 | 02/16/95 | Callbrated | ? | c | | 7 | Ņ | 0 | - | | | - | • | | > | -5 | -5 | ကု | + | - | က္ | |
| | Short Term Test | Week 1 | 02/10/95 | Calibrated | -3 | -5 | • | 4 | ņ | ဇှ | 6- | • | , | - | 7 | ٠ | ? | -3 | 6- | 4 | , | 7 | ιΰ | |
| | 7 | | Expected | 0.0 | 1.0 | 2.0 | c | 9.0 | 4.0 | 5.1 | 6.1 | | | 8.1 | 7.1 | | 5 i | 5.1 | 4.0 | 3.0 | 000 | | 1.0 | 0.0 |
| | 10.1% CO2 | . ; | Stec | 0 | 9 | 20 | 5 | 3 | 9 | 20 | 09 | 02 | 2 3 | 80 | 2 | 9 | 8 6 | 20 | 4 | ၉ | 20 | 3 : | 2 | 0 |
| | | | | | | | | | | | | | | | | | | | | | | | | |

| | Vool V | • | OOOOO | c | 4 | - + | - - | | - | • | - - | • | - | 0 | 0 | - | | - | - ‹ |) | - , | | 0 | Ċ. |
|-----------|---------|----------|------------|-----|--------------|----------------|-----|----------------|----------|----------------|-----|----------------|-----------|------------|---|-----|-----|-----|-----|-------|----------------|-----------|------------|-----|
| | Wook 12 | 1000 | celocico | • | | י מ | 0 | 0 | - | - • | - | - c | | o · | - | 0 | · c | , | - c | 7 | V (| 5 (| N | 0 |
| | Week 11 | 0679406 | 03/24/83 | 7 | - | 4 - | 6 | ı - | - | | - | - 0 | ، | n | 2 | - | - | - | - c | ۰, | V + | - , | - | φ |
| | Week 10 | 05/36/05 | 3 | 4- | c | · - | - | · c | c | c | | · | - - - | | _ | 0 | - | - | ٠ . | | | - . | _ | က် |
| | Week 9 | 05/11/05 | | ď | P | · - | - | · c | - | ٠ ، | ļ., | - | | - ' | - | - | - | ď | 1 7 | - | · • | | - ' | ι'n |
| | Week 8 | 05/04/05 | | ç | | | 2 | 10 | - | • - | 1 | 7 | | - • | - | 0 | - | - | ٠ ح | - | - c | - | _ (| ώ |
| | Week 7 | 04/28/95 | Calibrated | ιĻ | - | | - | 0 | - | ې ، | - | ٠ ، | - | - • | - | - | | 6- | | - - | · - | | - (| φ |
| | Week 6 | 04/20/95 | | Ģ | -2 | · - | - | ? | ဇှ | -5 | -3 | ņ | ç | Ņ | ? | ကု | ņ | 6 | ď | , | ו מי | 9 | u c | φ |
| | Week 5 | 04/13/95 | | φ | ကု | ņ | -5 | Ņ | ကု | Ņ | ç | ıņ | - | - c | , | ကု | ဗှ | ဇှ | - | ٠, | ıσ | 9 | ÷ | 01- |
| | Week 4 | 04/05/95 | | -7 | ç | ņ | - | çi | ę. | ဗု | ဗု | ņ | ç | , 4 | , | ကု | 4- | 6- | ę | ç | ιę | Ą | ٠ د | ņ |
| | Week 3 | 03/30/95 | | φ | -5- | Ţ | - | ç. | ဇှ | Ċ | ဇှ | ကု | ç |) r | 2 | ကု | -3 | က္ | ç | 2 | ņ | e, | | 70 |
| | Week 2 | 03/20/95 | | φ | 7- | Ņ | ٠ | -5 | ņ | Ģ | 4 | 6- | - | ٠ د | , | ώ | င့ | 4 | ဗု | -5 | ń | ç | ıq | ņ |
| | Week 1 | 03/15/95 | Calibrated | 4- | -5 | - | - | -5 | ç | -5 | -5 | ņ | ŀ | ٠ و | , | ņ | ဇှ | ဇှ | ņ | ? | ņ | c | , 1, | • |
| | Week 4 | 03/08/95 | Calibrated | -3 | - | 0 | 0 | ÷ | ņ | 1 | ç | -1 | | ن ، | , | Ţ | -5 | ņ | 0 | 0 | 7 | -2 | ď | , |
| | Week 3 | 02/27/85 | Calibrated | 9- | - | 0 | 0 | - | ņ | +- | Ģ | -1 | - | ç | | Ņ | -5 | ကု | ņ | · | - | Ş | ç | ı |
| | Week 2 | 02/16/95 | Calibrated | 6. | T | ٥ | 0 | - | - | - | 7 | - | 0 | 7 | | _ (| ķ | Ţ | 0 | 0 | 0 | - | 4- | r |
| | Week 1 | 02/10/95 | Calibrated | ç | 0 | - | - | - | çμ | 7 | - | - | 0 | Ţ | | | - | ç | -5 | 7 | ? - | - | κ | ı |
| 20. | | Expected | 0.0 | 0.5 | 0.1 | 1.5 | 2.0 | 2.5 | 3.0 | 3.5 | 4.0 | 4.5 | 5.0 | 4.5 | 4 | | 3.5 | 3.0 | 2.5 | 2.0 | 1.5 | 1.0 | 0.5 | 0.0 |
| 5.04% CO2 | | Stec | | - | | - 1 | | - | | | | - 1 | 5 | 8 | G | 8 8 | 5 | 8 | 20 | 40 | 30 | 50 | 9 | 0 |

Note: Bold Values Exceed Test Regiurements

Table 2D (cont.)

Relative Percent Error

| 2.48% CO2 | C02 | Short Term Test | m Test | | | _ | Long Term Test | ו Test | | | | | | | | | | |
|-----------|----------|-----------------|------------|------------|------------|------------|----------------|------------|----------|----------|-------------|------------|----------|----------|------------|----------|----------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 02/10/95 | 02/16/95 | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/05/85 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/16/95 | 05/24/95 | 05/30/85 | 06/06/95 |
| 0 | 0.00 | Calibrated | Calibrated | Calibrated | Calibrated | Calibrated | | | | | | Calibrated | | | | | | |
| 9 | 0.3 | ņ | 6- | 9- | -4 | -11 | Ģ | -7 | 6 | -13 | | 6- | φ | 9 | 9- | 4 | ç | φ |
| 8 | 0.5 | 7 | -1 | 6. | -2 | 2- | ç | 4 | ç- | ٩ | 4- | -4 | - | ę- | <u>ڊ</u> - | ņ | 2 | ? |
| ၉ | 0.8 | -5 | -5 | 4- | -5 | ф | ċ | 4 | ç | -7 | ę, | 4- | 7 | က္ | ဖှ | 0 | - | Ņ |
| 40 | 0.1 | - | - | τ- | 0 | 4 | -5 | Ţ | ç | ဗု | - | - | - | 0 | 0 | - | 2 | 0 |
| 20 | 1.3 | 0 | 0 | -5 | 0 | -5 | ç | 0 | - | 5 | 0 | 0 | 2 | ٥ı | 8 | က | 4 | N |
| 9 | 5: | 7 | - | e- | - | e- | 6- | - | ဗ | ဇှ | ÷ | ÷ | 0 | - | 0 | 2 | 2 | 0 |
| 20 | 1.8 | 0 | 0 | -2 | 0 | -3 | - | - | - | 7 | 0 | 0 | - | - | - | ო | က | Q |
| 80 | 2.0 | 0 | 0 | 7 | 0 | 4- | -5 | 2 - | ?- | -5 | - | 0 | - | ٥ | - | 2 | 8 | 0 |
| 6 | 2.3 | - | - | - | 0 | -5 | - | Ţ | | 7 | - | 0 | | 0 | , | ય | Ø | - |
| 9 | 2.5 | _ | - | - | - | -3 | -5 | -5 | -5 | -5 | -5 | 0 | 0 | 0 | 0 | 2 | 8 | 0 |
| 8 | 2.3 | - | - | -1 | 0 | ? | - | Ţ | 7 | 7 | - | - | - | 0 | 0 | ო | ო | 0 |
| 80 | 5.0 | - | Ψ. | ņ | - | -3 | -5 | -1 | ç | -5 | 0 | - | - | 0 | - | 2 | 2 | - |
| 20 | 1.8 | 0 | + | -2 | 0 | -3 | 1 | - | - | τ. | 0 | 0 | - | - | - | c | 8 | N |
| 9 | 1.5 | ņ | 7 | ကု | · | 6- | -3 | -5 | 6- | 0 | -5 | - | 0 | - | - | 2 | 2 | 0 |
| 20 | 1.3 | - | - | -4 | 0 | 4 | -5 | _ | ċ | ç | 8 | 0 | 2 | 0 | 0 | 8 | 4 | |
| 9 | 1.0 | ņ | 7 | က် | - | 4 | ဇ- | -5 | 6- | -3 | -5 | -5 | 0 | 0 | - | - | - | 0 |
| 8 | 9.0 | 4 | 4- | -8 | -4 | -2 | 9- | -5 | 9- | -7 | 4- | τċ | ဗု | 4 | ကု | τ | , | 6- |
| 20 | 0.50 | 4 | ကု | တု | 4- | 6- | 9 | 9- | -7 | φ. | ιċ | 4 | 6- | 6- | 4- | ç. | - | ? |
| £ . | 0.25 | -2 | φ | -22 | φ | -13 | ę, | ō, | - | -14 | -10 | 6- | မှ- | -7 | φ | -7 | ņ | φ |
| 0 | 0.00 | | | | | | | | | | | | | | | | | |

0.26% CO2

| 0.26% CO | 202 | | | | | | | | | | | | | | | | | |
|----------|----------|----------|----------|------------------|------------|------------|----------|----------|----------|----------|----------|------------|-----------|----------|----------|----------|----------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 02/10/95 | 02/16/95 | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/05/95 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/16/95 | 05/24/95 | 05/30/95 | 06/06/95 |
| 0 | 0000 | | | Calibrated | Calibrated | Calibrated | | | | | | Calibrated | | | | | | |
| 0 | 0.025 | • | • | 玖 | 97 | -38 | -85 | 69- | -65 | -62 | • | 11. | -58 | -50 | -46 | -35 | -35 | -58 |
| 50 | 0:020 | | | -19 | 65. | -15 | -25 | -29 | -27 | -25 | • | -29 | -21 | -19 | -17 | -13 | -12 | -19 |
| 30 | 0.075 | _ | ٠ | -13 | -10 | -13 | -22 | -21 | -19 | -18 | • | -22 | -14 | -14 | -13 | 6- | 6 | -14 |
| 40 | 0.100 | | | -13 | -12 | -14 | -20 | -50 | -19 | -18 | | -20 | -12 | -15 | -14 | -12 | -10 | -13 |
| 20 | 0.125 | ٠ | • | -18 | -15 | -18 | -22 | -22 | -22 | -21 | | -55 | -17 | -17 | -16 | -15 | <u>+</u> | -17 |
| 9 | 0.150 | | | -19 | -19 | -21 | -24 | -24 | -24 | -22 | | -23 | -21 | -50 | -19 | -19 | -17 | -19 |
| 20 | 0.175 | - | | -22 | -22 | -23 | -26 | -26 | -26 | -25 | • | -56 | -23 | -2 | -22 | -55 | -10 | -24 |
| 80 | 0.200 | | | -10 | -8 | -12 | -17 | -50 | -18 | -16 | • | -18 | -10 | | -12 | ဇု | -2 | ÷ |
| 06 | 0.225 | • | | 9- | 9- | 6- | -15 | -15 | -15 | -13 | • | -13 | ထု | 7- | φ | φ | 4- | œρ |
| 9 | 0.250 | | | 4- | 4- | æ | -12 | -12 | -11 | -10 | * | -10 | ç | φ | 7- | 4- | -2 | -7 |
| 06 | 0.225 | ٠ | • | -7 | -5 | -10 | -14 | -14 | -13 | -12 | • | -12 | ဖု | တု | 6- | -7 | 9 | 6- |
| 80 | 0.200 | | | -13 | -10 | -13 | -18 | -20 | -19 | -17 | | -17 | -12 | -12 | -12 | -10 | 8- | -12 |
| 20 | 0.175 | | | -23 | -23 | -24 | -26 | -27 | -26 | -25 | • | -26 | -53 | -53 | -23 | -21 | -12 | -23 |
| 09 | 0.150 | | | -21 | -20 | -22 | -24 | -24 | -24 | -22 | * | -24 | -21 | -21 | -50 | -19 | -17 | -21 |
| 20 | 0.125 | | • | -18 | -16 | 12 | -22 | -23 | -22 | -21 | • | -21 | -17 | -17 | -15 | -15 | -15 | -18 |
| 4 | 0.100 | | | 91- | -13 | -16 | -20 | -22 | -19 | -19 | | -22 | -15 | -15 | -12 | -13 | -11 | -15 |
| 30 | 0.075 | | | -17 | -14 | -17 | -23 | -19 | -21 | -21 | • | -53 | -14 | -17 | -14 | -13 | -10 | -14 |
| 20 | 0.050 | - | | -23 | -17 | -19 | -29 | -29 | -29 | -27 | • | -35 | -15 | -21 | -15 | -13 | -13 | -21 |
| 9 | 0.025 | , | | 6 9 ~ | -50 | S, | 89: | -73 | -69 | 69- | • | -81 | -54 | S, | -46 | 46 | 827 | -62 |
| 0 | 0000 | | | | | | | | | | | | | | | | | |

User Error - Data and calibration loss. Recalibrated prior to week 7

Table 2E GeoS Short-term and Long-term Testing

| 10.1% CO2 | C02 | Short Term Test | m Test | | | | Lona Term Test | . Test | | | | | | | | rg. | • | |
|-----------|----------|-----------------|------------|------------|------------|------------|----------------|----------|----------|----------|----------------|------------------|--------|----------|----------------|----------|----------------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Wook 9 | Week 10 | Week 11 | Wook 19 | Mook 12 |
| Stec | Expected | 02/10/95 | 02/16/95 | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/05/95 | 04/13/95 | 04/20/95 | 04/28/05 | DSAMAR | 06/11/06 | 05/16/05 | 000400 | ornoni | CI Vacan |
| 0 | 0.0 | Calibrated | Calibrated | Calibrated | Calibrated | Calibrated | | | | | 2 | Callbrated | 0000 | CS/II/CO | 68/01/60 | 05/24/95 | 05/30/85 | 06/06/95 |
| 2 | 1.0 | -5 | -5 | ဗု | ç | 4- | φ | ç | 4 | ď | ų | Calibrated -5 | 5 | * | • | c | c | |
| 8 | 5.0 | - | - | - | c | c | - | , | | , | , | 2 | , | , | , | 7. | 2- | ? |
| 30 | 0.6 | | | | | | - , | _ , | ۰ د | _ | _ | > | _ | 0 | - | 7 | 2 | |
| \$ | | , | - | - , | 3 | 0 | - | - | ٥ | • | - | 0 | _ | - | , | 2 | 8 | _ |
| ⊋ ¦ | . t | _ | > | 0 | _ | ဇှ | çį | ņ | ç; | ç | 7 | _ | - | c | c | - | 0 | c |
| 22 | 5.1 | çį | - | -1 | ņ | ? | ကု | ဗု | ņ | ιċ | eņ | - | ٠, | ٠, | · - | | · • | • |
| 9 | 6.1 | ကု | 0 | - | -5 | -2 | 2 | 6. | 4 | ب | 9 | - | | | - - | | - | - |
| 20 | 7.1 | ņ | - | - | ņ | ç | ij | י רי | o c | , u | , с | - < | o 6 | - (| . . | - (| - (| - |
| G | τ | - | | | | | | | 4 | , | Ņ | 2 | 7. | 0 | ٥ | 2 | 0 | - |
| 3 8 | | - (| - (| _ (| _ | _ | | 7 | - | κ̈́ | - | - | 0 | 0 | - | 4 | - | 0 |
| 2 | | ? | 0 | 2- | -5 | -5 | -5 | -3 | ဇှ | φ | က္ | 0 | 7 | - | - | ۳. | | ۹, |
| 9 | 6.1 | ကု | - | ņ | ņ | ņ | ကု | 4- | 6- | ç | ń | - | | - | 5 | - | \ - | 100 |
| 20 | 5.1 | -5 | -1 | · | Ņ | ņ | ကု | 4- | 7 | ιć | 4 | ر. | | | J * | - • | , , | Ņ • |
| 4 | 4.0 | 7 | 0 | - | _ | -5 | ę, | ? | ç | e, | | - | | , | | | - | - , |
| 30 | 3.0 | 0 | 0 | 0 | c | - | ņ | ۱۹ | ٠, | ۰ ۹ |) , | | - • | - ‹ | > 0 | - (| o (| - · |
| 20 | 2.0 | c | - | ٥ | | | | 4 | - - | 9 | 1 | , | - - | 0 | 0 | 7 | ٥ | ٥ |
| F | - | , « | ٠ ، | , • | , • | ۰ د | ו וי | - ' | - ' | - | 7 | _ | 0 | 0 | 0 | 2 | _ | _ |
| 20 | 0.0 | ? | ŗ | ŧ | † | - | , | φ | φ | φ | | ψ | 4 | ι'n | 4 | Ġ | -5 | ဇှ |
| , | | | | | | | | | | | | | | | | | | |

| Ç | ų |
|---|---|
| c |) |
| Ć | ١ |
| | 0 |
| 0 | ` |
| 4 | r |
| C | 2 |
| | |

Note: Rold Values Exceed Test Beginsenerte

Table 2E (cont.)

Relative Percent Error

| 2.48% CO2 | C02 | Short Term Test | rm Test | | | _ | Long Term Test | ı Test | | | | | | | | | | |
|-----------|----------|-----------------|------------|------------|----------|------------|----------------|----------|----------|----------|----------|------------|----------|----------|----------|----------|----------|----------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 02/10/95 | 02/16/95 | 02/27/95 | 99/90/60 | 03/15/95 | 03/20/95 | 03/30/95 | 04/05/95 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/16/95 | 05/24/95 | 05/30/95 | 06/06/95 |
| 0 | 0.00 | Calibrated | Calibrated | Calibrated | 8 | Calibrated | | | | | | Calibrated | | | | | | |
| 9 | 0.3 | -10 | -13 | -19 | -19 | -22 | -20 | -21 | -23 | -52 | -23 | -23 | -20 | -21 | -19 | -17 | -17 | -19 |
| 20 | 0.5 | 7 | က္ | -7 | ۲. | 9- | | 8- | 6- | ę. | ę | ę. | -7 | 89 | 9 | 4- | 4- | 9- |
| 90 | 0.8 | - | -5 | မှ | ٩ | æ | -7 | 9- | -8 | -2 | œ | -7 | ņ | φ | 4 | ņ | ņ | 4- |
| 40 | 1.0 | 7 | ç. | 4 | - | ကု | | 4- | 4 | 4 | 4 | 4 | ဗု | 6- | -2 | - | 0 | -5 |
| 20 | 1.3 | ٥ | ۲. | -5 | -5 | -4 | | 7- | ကု | ကု | ċ | ကု | - | 5 | - | 0 | - | - |
| 9 | 1.5 | - | - | ń | Ņ | ဇှ | | -5 | က္ | -5 | -5 | ဇှ | - | • | - | - | - | 0 |
| ٩ | 1.8 | ٥ | ٥ | 5 | - | -1 | - | - | T | - | - | 0 | 0 | 0 | - | က | Q | ~ |
| 8 | 2.0 | 0 | 0 | 7 | - | çį | - | 1 | - | 0 | - | - | - | 0 | - | 2 | 2 | - |
| 8 | 2.3 | ٥ | - | - | ÷ | 6- | 0 | - | - | 0 | _ | 0 | - | 0 | ۲, | e | e | _ |
| 8 | 2.5 | 0 | 0 | - | 0 | 0 | 0 | 0 | 0 | - | 0 | - | 2 | 0 | 2 | 4 | က | 6 |
| 8 | 2.3 | - | - | - | - | - | - | - | 0 | 0 | - | - | - | 0 | Q | e | m | 0 |
| 80 | 2.0 | 0 | - | ņ | Ţ | - | 0 | 0 | - | 0 | 0 | 0 | - | 0 | - | ~ | 2 | - |
| 2 | 1.8 | ٥ | - | -5 | - | -5 | - | - | -1 | + | - | 0 | 0 | 0 | 0 | 8 | n | - 01 |
| 09 | 5: | ٠, | Ņ | ņ | ώ | ကု | ? | çı | 7- | -5 | e- | -5 | - | ٣ | T | - | 0 | 0 |
| g | 1.3 | -5 | ۲۰ | 4- | 6- | 5 | -3 | ę- | ŵ | ကု | Ģ | မှ | Ņ | ņ | ç | 0 | 0 | |
| 5 | 1.0 | ç. | ņ | ιĊ | 4 | τċ | 4 | -5 | č. | 4 | ç | -5 | ဗု | 4- | 6- | - | - | -5 |
| 8 | 0.8 | -5 | 4 | 8- | -7 | 9- | -7 | 8- | ø, | -8 | 8- | œρ | φ | -7 | ç | ဇ္ | ę- | ÷ |
| 50 | 0.50 | ဇှ | ċ | o- | φ | Ŧ | 6 | φ | -10 | -10 | -5 | -10 | 2- | 6- | ė, | ç. | 4 | φ |
| 2 ∘ | 0.25 | . | 5 | 7. | -5- | -53 | -21 | -21 | -53 | -53 | -53 | -23 | -21 | -52 | -50 | -18 | -18 | 8- |
| | | | | | | | | | | | | | | | | | | - |

0.26% CO2

| 200%02.0 | ָ מַ | | | | | | | | | | | | | | | | | |
|----------|----------|----------|----------|------------|--------------|------------|----------|----------|----------|----------|----------|------------|----------------|----------|----------|-----------------|------------------|---------|
| | | Week 1 | Week 2 | Week 3 | Week 4 | Week 1 | Week 2 | Week 3 | Week 4 | Week 5 | Week 6 | Week 7 | Week 8 | Week 9 | Week 10 | Week 11 | Week 12 | Week 13 |
| Stec | Expected | 02/10/95 | 02/16/95 | 02/27/95 | 03/08/95 | 03/15/95 | 03/20/95 | 03/30/95 | 04/05/85 | 04/13/95 | 04/20/95 | 04/28/95 | 05/04/95 | 05/11/95 | 05/16/95 | 05/24/05 | 05/30/05 | OSOBOS |
| 0 | 0.000 | | | Calibrated | Calibrated | Calibrated | | | | | | Calibrated | | | | | | 2 |
| 10 | 0.025 | • | | -100 | -100 | -100 | -100 | -100 | -100 | -100 | * | .100 | -100 | -100 | 910 | -100 | .100 | 707 |
| 50 | 0.050 | | | 9- | -62 | -62 | -83 | -87 | -75 | -92 | • | -100 | -87 | -8.7 | 69- | car | 89- | |
| 30 | 0.075 | | • | -28 | -28 | -28 | S. | ŝ | 45 | -55 | • | 9 | ÷ ' | 34 | 15 | , P | 96. | : \$ |
| 40 | 0.100 | <u>.</u> | | 51. | -13 | -13 | -36 | 37 | 31 | -37 | • | 141 | 757 | 35. | -25 | 36. | 36. | ř |
| 20 | 0.125 | _ | | 6- | Ģ. | φ | -28 | -29 | -25 | -31 | • | : 27 | -26 | -28 | ې دې | 3 = | 61- | . c. |
| 09 | 0.150 | | | 6- | မှ | φ | -25 | -26 | -24 | -28 | | -29 | -23 | -24 | 6- | -12 | 10. | 16. |
| 20 | 0.175 | | | 8- | -2 | -2 | -24 | -25 | 12 | -25 | • | -26 | 50 | -55 | 5 | <u> </u> | ÷ | د د |
| 8 | 0.200 | | | <i>L</i> - | -2 | -2 | -23 | -24 | -21 | -24 | | -25 | -21 | -21 | -18 | 14- | <u>=</u> | 6- |
| 8 | 0.225 | | - | 6- | -7 | -2 | -53 | -24 | -21 | -25 | • | -26 | -21 | -55 | · 4- | -17 | ÷ c , | - 2 |
| 8 | 0.250 | | | -10 | ن | -3 | -23 | -25 | -22 | -24 | | -24 | -22 | -23 | -20 | -19 | 6- | 2,5 |
| 6 | 0.225 | • | ١. | -10 | 80 | φ. | -24 | -24 | -21 | -52 | • | -52 | -21 | -55 | 6- | -17 | 6 | ρ - |
| 8 | 0.200 | | | ф | -7 | <i>L</i> - | -23 | -24 | -22 | -24 | | -25 | -22 | -22 | -17 | -12 | -17 | 6 |
| 2 | 0.175 | , | • | 6- | .7 | | -24 | -25 | 7 | -25 | • | -26 | -55 | -24 | 8 | 9- | ξ. | 9 5 |
| 8 | 0.150 | | , | | 6. | 6- | -26 | -27 | -23 | -28 | • | -28 | -22 | -24 | 6. | -12 | ٠ و | .5 |
| 20 | 0.125 | | , | .12 | -12 | -12 | 87- | -29 | -55 | 32 | * | 88- | -28 | -28 | ÷ | <u>α</u> | ÷ ÷ | . ? |
| 4 | 0.100 | | | -20 | -11 | -17 | -35 | -37 | -33 | 38 | • | -40 | -33 | 23.4 | 36. | PC- | 30. | 96. |
| 8 | 0.075 | • | | -32 | -32 | -32 | 49 | 95- | 4 | 95 | • | 9 | S | Ę |) F, | , K | (2) | 9 00 |
| 20 | 0.050 | | ١. | -62 | 69- | 69- | -83 | 96- | -75 | -84 | | -100 | -87 | -85 | 19- | 69- | 73 | 2 |
| 우 | 0.025 | | | -100 | -100 | -100 | -100 | -100 | 91. | -100 | • | -100 | -100 | 901- | (e) F- | ; \$ | | 3 5 |
| c | 0000 | | | | | | | | | | - | | | | | 3 | 2 | |

* User Error - Data and calibration loss. Recalibrated prior to week 7

FIGURE LEGENDS

Fig. 1.

<u>Testing Setup</u>. Setup showing how test gases were delivered to the analyzers via STEC device during testing.

Fig. 2a-e.

<u>Short-term accuracy</u>. Relative error for measurements from 1 to 8% CO₂ immediately after instrument calibration using 8% CO₂. Calibration and testing done weekly for 4 consecutive weeks.

Fig. 3a-e.

Response Curves. Analyzer response curves for 4 gas standards: 0.25, 2.5, 5, and 10% CO_2 . Data from one week's short-term accuracy test. Relative error plotted vs. CO_2 concentration. Analyzer calibrated with 1 of the 4 standards. STEC gas divider then used to deliver 0 to 100 to 0% of the standard concentration. For the 8% standard, STEC was varied only from 0 to 80 to 0%, resulting in a maximum concentration of 8%.


Fig. 4a-e.


<u>Long-term accuracy</u>. Relative error for measurements from 0.25% to 8% over 13 weeks after a one-time calibration with 8% CO₂ at the beginning of the test.


Fig. 5a-b.


Ambient temperature. Effect of ambient temperature change on instrument measurement of 8% after calibration with the same. Instruments were tested first at ambient temperature (~20 °C), then 2 h after being cooled (~12 °C) or heated (~34 °C). Each instrument underwent 2 sequences of ambient, then cooling, then heating, and another 2 sequences of ambient, then heating, then cooling. Drift defines the change in instrument reading for each degree C.


Figure 1 Testing setup
















Figure 3A Enmet Response Curves











Figure 3B RKI Response Curves












Figure 3C Nova Response Curves











Figure 3D GeoL Response Curves















Figure 3E GeoS Response Curves


























APPENDIX A: INSTRUMENT REVIEW AND SELECTION.

The 5 candidates analyzers chosen for testing by NMRI are listed below.

| PAGE | MANUFACTURER | MODEL |
|-------------|-------------------------|---------------------------|
| 52 | Enmet Corp. | CD-1300-P, 0 TO 10% |
| 55 * | Geotechnical Inst. Inc. | CDM-1000/long, 0 to 7.5% |
| 55 | Geotechnical Inst. Inc. | CDM-1000/short, 0 to 7.5% |
| 63 | NOVA Analyt. Sys., Inc. | 302 BD, 0 to 10% |
| 64 | RKI Instruments, Inc. | RIKEN RI-411A, 0 TO 9.95% |

*SELECTED AS BEST OF ALL CANDIDATES

The following vendors make instruments that are either portable or transportable. Only a few make units that are portable and cover the full 10.0% range. None operate under hyperbaric conditions. Vendors that were contacted but do not have applicable instruments are listed at the end of the Appendix.

| PAGE | ı <u>'</u> | <u>MANUFACTURER</u> | |
|------|---------------|---|--|
| 50 | | California Analytical (formerly: Milton Roy) | |
| 51 | | Columbus Instruments, Div. International Instr. Co. | |
| 52 | * | Enmet Corp. | |
| 53 | | Enviromax/Tess-com, Inc. | |
| 54 | | Gas Tech, Inc. | |
| 55 | ** | Geotechnical Instruments, Inc. | |
| 56 | | Horiba Instruments Inc. | |
| 57 | | Illinois Instruments, Inc. | |
| 58 | | Landtec Inc. | |
| 59 | | Li-Cor Inc. | |
| 60 | | Metrosonics Inc. | |
| 61 | | MSA Instr. | |
| 62 | | National Draeger, Inc. | |
| 63 | * | NOVA Analytical Systems, Inc. | |
| 64 | * | RKI Instruments, Inc. | |
| 65 | | Sensidine, Inc. | |
| 66 | | Servomex Co. | |
| 67 | | Shimadzu Scientific Instruments, Inc. | |
| 68 | | Siemens Industrial Automation, Inc. | |
| 69 | | Telaire Systems, Inc. | |
| 70 | | Teledyne Brown Engineering, Analytical Instruments. | |

^{*} Tested as a candidate analyzer.

^{**} Tested and selected as the final and best of all candidates.

California Analytical (formerly:Milton Roy) Attn: Fred Christ 1238 West Grove Ave.

Orange, CA 92665-4134

(714)-974-5560 FAX (714)-921-2531

Model:

ZFP-5

Price:

\$2990.00

Method:

NDIR

Ranges:

0-2000, 0-5000 PPM, 0 to 2 % & 0 to 5 %(dual range)

Power:

115 Vac or rechargeable battery

Sampling pump:

built in/10 s response

Alarms:

none

Display:

Analog

Accuracy:

 \pm 5% of full scale

Repeatability:

 \pm 5% of full scale

Zero drift at constant temp:

not specified

Zero drift temp effect:

not specified

Operating temp range:

32-104 °F (0-40°C)

Storage temp:

not specified

Weight: Dims:

13 lbs. (6 kg.) 8.5x6.1x10.4 in. (215x155x265mm)

Output signal:

0-100mV DC

Calibration:

not specified

Cal controls:

zero & span

TEST RESULTS: On 1/21/92 the unit was briefly tested at NMRI/Lab 103. The test consisted of a few zero and span measurements which were within the stated accuracy on both ranges. The unit was placed in a small animal hyperbaric chamber and pressed to 100 FSW, during a short exposure (less than 10 minutes), the unit read a steady value (400 PPM). The unit was returned to room pressure and retests showed normal operation.

Columbus Instruments, Div. International Instr. Co.

950 N. Haque Ave.

P.O. Box 44049

Columbus, OH 43204

(800)669-5011

Fax (614)276-0529

Model:

Model-180/8200-D-30/8203-D-30

Price:

\$4,900.00

Method:

NDIR

Ranges:

0-10%

Power:

115 Vac only

Sampling Pump:

Internal/100-650 ml/min

Alarms:

none

Display: Accuracy:

digital

Repeatability:

± .01%

Repeatability.

 \pm .04%

Zero drift at constant temp: .03%

Zero drift temp effect: Operating temp range:

Storage temp:

Weight:

22 lb/9.75 kg

Dims:

11x11.5x14 in.

Output signal:

Calibration:

?

Cal controls:

zero/span

TEST RESULTS: None

COMMENTS: This is a "high accuracy" unit not suitable for this study.

ENMET CORP. P.O. BOX 97 680 Fairfield Ct. ANN ARBOR, MI 48867-0979 (313)-761-1270 Fax (313)-761-3220

Model:

CD-1300-P portable carbon dioxide analyzer

Price:

\$1895.00

Method:

NDIR

Ranges:

Std,0-5000PPM, Opt, 0-10%, 0-20%, 0-100%

Power:

9.6V rechargeable batt, operates 12 h on 1 charge, can be

operated off of charger

Sampling pump:

built in with 500 cc/min flow

Alarms:

high & low gas, low flow

Display:

Analog

Accuracy:

±3% of full scale

Repeatability:

±1% of full scale

Zero drift at constant temp: <0.2% CO₂ per mo. Zero drift temp effect:

<0.2% CO₂ per deg. C

Operating temp range:

15 to 140 °F (-10 to 60 °C)

Storage temp:

-5 to 160 °F (-20 to 70 °C)

Weight:

3.5 lb (1.5 kg.)

Dims:

3x5x8.5 in. (7.5x14x22cm.)

Output signal:

0-1Vdc (0 to full scale, non-linear)

Calibration:

Every 3 to 4 months

Cal controls:

zero & span

TEST RESULTS: Difficult to calibrate.

Enviromax/Tess-Com, Inc.

Distributor:

18900 Teller Ave.

Tess-Com/Lou Colonna

Irvine, CA 92715

Butler, PA

(714)863-9443

(412)233-5782

Fax (714)756-1635

Model:

enviromax 3000

Price:

\$6395.00

Method:

NDIR

Ranges:

0-10,000 PPM

Power:

Battery/rechargeable

Sampling Pump:

internal, 0.2-2 LPM

Alarms:

audible

Display:

digital

Accuracy:

± 3 ppm or 0.1% of full scale

Repeatability:

± 3 ppm

Zero drift at constant temp:

<3 ppm per 24 h

Zero drift temp effect:

not specified

Operating temp range:

-10 to 50 °C

Storage temp:

-10 to 80 °C 22 lbs. (10 kg)

Weight: Dims:

20x8x5 in. (50x22x13)

Output signal:

0-1,5,10Vdc

Calibration:

not specified

Canbranon.

zero/span

Cal controls:

zero/span

TEST RESULTS: none, but the navy has one in a Norfolk, VA facility.

<u>COMMENTS</u>: Agent claims the unit is "top of the line & state of the art", more data needed, price seems very high for this study. Demo available for portable and rack mounted CO_2/O_2 version.

Gas Tech, Inc.

Distributor:

8407 Central Ave.

Jay Mottley.

Newark, CA 94560-3431

Carey Machinery, Co

(510)745-8700

3501 Brehns Ave.

Fax (510)794-6201

Baltimore, MD 21213

(410) 485-2323

Model:

3252 Carbon Dioxide GasTechtor

Price:

\$3100.00

Method:

NDIR

Ranges:

0 to 5% CO_2 and 0 to 25% O_2 is the only version made

Power:

Rechargeable battery

Sampling Pump:

built in

Alarms:

variable level

Display:

analog

Accuracy:

± 10% Of full scale

Repeatability:

± 5% of full scale

Zero drift at constant temp: no info Zero drift temp effect:

no info

Operating temp range:

0-40 °C

Storage temp:

no info

Weight:

8 lbs

Dims:

12x4x6 in.

Output signal:

optional, 0-100mV

Calibration:

no info

Cal controls:

no info

TEST RESULTS: none

COMMENTS: The vendor only markets a dual sensor CO₂/O₂ unit and the range is 0 to 5% which is too low for this application. One unit has been procured for the DDS project for evaluation as a backup unit.

Geotechnical Instruments, Inc

7507 Standish Pl. Rockville, MD 20855

(301)309-6580

Fax (301)309-6584

Distributor:

Joel Johnson PEDC, Inc. P.O. Box 7026

Wilmington, DE 19803

(302) 655-9291 Fax 655-8140

Model:

CDM-1000

Price:

\$4300.00

Method:

NDIR

Ranges:

0 to 7.5%

Power:

Battery/115Vac on recharger

Sampling Pump:

Internal @ 500-750 cc/min

Alarms:

none

Display:

digital

Accuracy:

± 10% of measurement/verified

Repeatability:

± 10% of measurement/verified

Zero drift at constant temp: not checked Zero drift temp effect:

~+10 ppm/-1°F

Operating temp range:

0-40 °C/32-104 °F

Storage temp:

Weight:

4.8 lb./2.2 kg

Dims:

8.7x8.9x2 in./22x22.6x5.1 cm.

Output signal:

RS 232

Calibration:

TBD

Cal controls:

Span only

TEST RESULTS: Tested 10/25/94. Accuracy/Repeatability/drift tests on low/high. 1,250/20,000 PPM gas showed that the unit has a maximum error of $\pm 3\%$ @ 1,250 PPM and \pm 7% @ 20,000 PPM.Linearity tests from 500-2,500 PPM were \pm 5%(below 500 PPM the error was 20%). From 5,000-25,000 PPM, the linearity was \pm 6%. Zero/span checks were within spec for 2 days, then the zero became offset by 600 PPM. After a 48 hour off cycle, the zero returned to normal. A telecon with Chris Sweet (Geotch. U.K.) indicated the problem may have been infusion of the 25,000PPM span gas into the interior of the case. It then takes time for this gas to exit since the case is sealed with a gasket. This fault has been corrected.

Horiba Instruments Inc.

Sales/Distributor:

1021 Duryea Ave. Irvine, CA 92714 (800)-446-7422 PENN-DEL 810 N. Pine Ridge Ct. R.T. Gondon (410)437-8785

Fax (714)-250-0924

Bel Air, MD 21014

(410)437-8785

(410)-893-7960

Model:

MEXA-211GE

Price:

\$1995.00

Method:

NDIR

Ranges:

0-19.995

Power:

120Vac, not battery operated

Sampling pump:

built in

Alarms:

multiple, gas, etc.

Display:

digital

Accuracy:

± (not avail)

Repeatability:

 \pm 0.3% or \pm 2%, whichever is greater

Zero drift at constant temp:

(not avail)

Zero drift temp effect:

(not avail)

Operating temp range:

0-40 °C

Storage temp:

(not avail)

Weight:

approx 14.4 lb (6.5 kg)

Dims:

10.3x6.3x14.2 in. (260x160x360cm.)

Output signal:

0-1Vdc

Calibration:

not specified

Cal controls:

not specified

TEST RESULTS: none

COMMENTS: Demonstration requested 8/22/94. R. Gondon sent Horiba a second request for a demo 11/1/94.

Illinois Instruments, Inc. 27840 Concrete Dr. Ingleside, IL 60041 (815)-344-6212 Fax (815)-344-6332

Model:

3700 Headspace Analyzer

Price:

\$4495.00

Method:

NDIR

Ranges:

0-100%

Power:

115Vac only

Sampling Pump:

internal

Alarms:

none

Display:

digital

Accuracy:

± 2% of measured value

Repeatability:

not specified

Zero drift at constant temp:

not specified

Zero drift temp effect:

not specified

Operating temp range:

not specified

Storage temp:

not defined

Weight:

not given

Dims:

11x10.5x4.5 in.

Output signal:

0-10V

Calibration:

not specified

Cal controls:

zero & span

TEST RESULTS: none

COMMENTS: No battery option; demo available if desired.

Landtec

6055 E Washington Blvd.

Commerce, CA

Distributor:

Hazco services Inc. 2006 Springboro West

Dayton, OH 45439 (513)-293-2700 Fax (513)-293-9227

Hot line (800)-332-0435

Model:

GA-90 Gas Analyzer

Price:

\$4875.00

Method:

NDIR

Ranges:

0-75%

Power:

Battery only?

Sampling Pump:

Internal

Alarms:

wet gas

Display:

digital

Accuracy:

 \pm 3%(per telecon, in 0-10% may be o.k.)

Repeatability:

not specified

Zero drift at constant temp:

not specified

Zero drift temp effect:

not specified

Operating temp range:

32 - 104 °F not specified

Storage temp:

"light weight"

Weight:

Dims: Output signal: "compact"

none

Calibration:

not specified

Cal controls:

not described

TEST RESULTS: No test.

COMMENTS: This unit is made by Geotechnical Instruments and is similar to Geotechnical CDM-1000. Landtec is the U.S. distributor.

LI-COR, Inc.

4421 Superior St.

P.O. Box 4425

Lincoln, NE 68504

(800)-447-3576 (402)-467-3576 FAX (402)-467-2819

Model:

LI-6252/LI-670

Price:

\$7300.00/\$2375.00

Method:

NDIR

Ranges:

0-1000 & 0-5000 ppm

Power:

120 Vac & rechargeable batt. pack (10.5 - 16Vdc)

Sampling pump:

dual, variable flow, for sample & reference (if needed)

Alarms:

none

Display: Accuracy:

digital

Repeatability:

±5 ppm

Zero drift at constant temp: <10 ppm per 24 h

±1 ppm

Zero drift temp effect:

0.5 ppm per °C

Operating temp range:

not specified

Storage temp:

not specified

Weight:

7.7 lb (3.5 kg.)

Dims:

13x33.5x24cm.

Output signal:

RS-232c,100mV,5V,±15V (non-linear) & 4-20 mA

Calibration:

daily

Cal controls:

Zero, span

TEST RESULTS: A 6252/670 combination has been used for 2 years as a bench top unit with no problems. Accuracy and stability are to specification.

<u>COMMENTS</u>: This system is NOT rugged, corpsman friendly or low cost. This system should be used as a performance standard with which candidate analyzers should be compared.

Metrosonics Inc.

General Products Div.

P.O. Box 23075

Rochester, NY 14692

(716)-334-7300

Fax (716)-334-2635

Distributor

NCP/Analytical Inst. Inc.

512 Interchange Blvd.

Newark, DE 19711

(800)-346-0304

Fax (302)-733-0948

Model:

aq-511

Price:

\$2290.00 (with batt. pack)

Method:

NDIR

Ranges:

0-5000 ppm

Power:

114Vac & battery pack

Sampling Pump:

Internal @ 1 LPM

Alarms:

high gas option

Display:

digital

Accuracy:

 \pm 3% of full scale

Repeatability:

± not specified

Zero drift at constant temp:

not specified

Zero drift temp effect:

not specified

Operating temp range:

32 - 122 °F (0-50 °C)

Storage temp:

-4 - 140 °F ((-20)-60 °C)

Weight:

8.2 lb (3.7 kg)

Dims:

10.1x12.3x4 in. (25.7x31.2x10.3 cm)

Output signal:

0 - 1V

Calibration:

daily

Cal controls:

Zero & span

TEST RESULTS: None

COMMENTS: This unit does not cover the full range (7.5%)

MSA Instruments

Portable Regional Office MSA/36 Great Valley Rd.

P.O. Box 426 Pittsburgh, PA 15230

Malvern, PA 19355

(800)-672-2222

(800)-672-2222 (ask for Malvm)

FAX (610)-647-8893

Model:

ACO₂ Hand Held Indicator

Price:

\$1600.00

Method:

Electrochemical pH sensor

Ranges:

0.03% to100%

Power:

4AA batteries

Sampling Pump:

diffusion or hand pump

Alarms:

dual gas levels & low battery

Display:

digital

Accuracy:

 $\pm 0.02\%$ @ 10% range

Repeatability:

± not specified

Zero drift at constant temp: not specified

Zero drift temp effect:

not specified 32-113 °F (0-45 °C)

Operating temp range: Operating Pressure range:

700-1060 hPa

Storage temp:

not specified

Weight:

11 oz. (310 gm.)

Dims:

2.3x1.6x6.2 in. (60x42x160 cm.)

Output signal:

none

Calibration:

unknown

Cal controls:

not specified

TEST RESULTS: none

COMMENTS: sensor life is one year; electrolyte must be replaced every 3 mos.

National Draeger, Inc.

101 Technology Dr.

P.O. Box 120

Pittsburgh, PA 15230 (800)-922-5518

Fax (800)-922-5519

Distributor:

NCP/Analytical Instr. Inc. 512 Interchange Blvd.

Newark, DE 19711

(800)-346-0304

(302)-733-0948

Model:

Multiwarn Portable Gas Monitor

Price:

\$5300.00 Unknown

Method: Ranges:

0-9999 PPM

Power:

Battery only

Sampling Pump:

Internal and diffusion

Alarms:

low flow and gas

Display:

digital

Accuracy:

no data

Repeatability:

no data

Zero drift at constant temp:

no data

Zero drift temp effect:

no data

Operating temp range:

(-5)- 105 °F (-20 to 40 °C)

Storage temp:

not specified 3.1 lbs. (1.4 kg)

Weight: Dims:

4.9x7.5x2.5 in. (12.4x19.0x6.3 cm)

Output signal:

PC interface

Calibration:

unknown

Cal controls:

unknown

TEST RESULTS: none

COMMENTS: Pricey...Demo requested 9/12/94

NOVA Analytical Systems, Inc. 1925 Pine Ave. Niagra Falls, NY 14301 (800)295-3771 Fax (716)282-2937

Model:

302BD Portable CO₂ Analyzer

Price: Method:

\$2645.00 NDIR

Ranges:

0-10%

Power:

115Vac & battery

Sampling Pump:

internal/

Alarms: Display: none digital

Accuracy: Repeatability:

± 2% of full scale

Zero drift at constant temp: 30 ppm per hour

± 2% of full scale

Zero drift temp effect:

2 ppm per deg. F

Operating temp range:

32-120 °F (0-50 °C)

Storage temp:

-20 to 130 °F (-30 to 55 °C)

Weight:

6 lb

Dims:

10x7.5x8 in.

Output signal:

0-1Vdc

Calibration:

suggested "yearly"

Cal controls:

span only

TEST RESULTS: During screening, the unit performed within 10% from 1 to 5%. Below 1%, the error was 20%. Accuracy & repeatability were better than 5%. Drift, short term, is not as good as desired, but is well within the required range. A daily calibration span check after a 30 min warm-up is recommended for best results.

RKI Instr. Inc.

Distributor

1855 Whipple Rd.

Advanced Control Technology

Hayward, CA 94544

P.O. Box 85

(800)754-5165 Fax(510)441-5650 2151 Johnson Rd. Rockville, VA 23146

(804)-749-3434

Model:

RIKEN RI-411A

Price:

\$3075.00

Method:

NDIR

Ranges:

0-10%

Power:

120Vac & batt. pack

Sampling Pump:

Internal diaphragm (1.2 LPM)

Alarms:

High CO₂ & Low batt

Display:

light coy as i

Dispidy.

digital

Accuracy: Repeatability:

 \pm 2% of full scale \pm 2% of full scale

Zero drift at constant temp: not specified

not specified

Zero drift temp effect:

not specified

Operating temp range:

14-104 °F (-10-40 °C)

Storage temp:

not specified

Weight:

6 lb

Dims:

10x7.5x4.5 in.

Output signal:

0-10 Vdc linear Based on tests, a daily check is desirable

Calibration: Cal controls:

Zero & Span

TEST RESULTS: The loaner tested did not have a 115Vac adapter so all tests were done with alkaline batteries. Linearity, accuracy and repeatability were within 5%. Even long term, zero drift was excellent.

Sensidine, Inc.

16333 Bay Vista Dr. Clearwater, FL 34620

(800)-451-9444

Fax (813)-539-0550

Model:

SS2000, Portable Gas Detector

Price:

???

Method:

Electrochemical

Ranges: Power:

1,000-10,000 PPM

Sampling Pump:

Battery/optional 115Vac none/diffusion

Alarms:

5,000 ppm

Display:

analog

Accuracy:

± 10%

Repeatability:

± 10%

Zero drift at constant temp:

not specified

Zero drift temp effect:

not specified

Operating temp range:

23-113 °F (-5 - 45 °C)

Storage temp:

not specified

Weight:

3.4 lbs. (1.5kg)

Dims:

8.5x4.4x6.8 in. (21.6x10.9x17.3 cm)

Output signal:

none

Calibration:

not specified

Cal controls:

not defined

TEST RESULTS: none

COMMENTS: electrochemical sensor has 3 year life. The lower range seems to start at 1000 PPM, more info is needed.

Servomex Co. 90 Kerry Pl. Norwood, MA 02062 (617)-769-7710 FAX(617)-769-2834

Model:

PA404

Price:

\$7500.00

Method:

NDIR

Ranges:

Varied, 0-10% available

Power:

120Vac & internal batt

Sampling Pump:

Internal (0.1-1 LPM)

Alarms:

High gas

Display:

digital

Accuracy:

± 1% full scale

Repeatability:

± 1% full scale

Zero drift at constant temp:

5%/7 Days

Zero drift temp effect:

0.3%/°C

Operating temp range:

32-104 °F (0-40 °C)

Storage temp:

not specified

Weight:

12.1 lbs. (5.5 kg)

Dims:

7.25x7.8x15 in. (185x220x390 mm)

Output signal:

0-100 mV

Calibration:

daily/not specified

Cal controls:

zero span

TEST RESULTS: This unit was given zero drift tests over an 8-hour period. On 120Vac, the unit had 0.1% drift and a second test showed no measurable drift when on battery operation for the same time.

<u>COMMENTS</u>: This unit was heavy with an unusual shape and costly, but its performance is excellent. Cost and size excluded it from consideration for this project.

Shimadzu Scientific Inst. Inc 7102 Riverwood Drive Columbia, MD 21046 (800)-477-1227 Fax (301)-381-1222

Model:

CGT-10-3A

Price:

\$9500.00

Method:

NDIR

Ranges:

dual up to 100% in 1/5 ratio

Power:

115Vac only

Sampling Pump:

internal @2.5 LPM

Alarms:

none

Display:

analog

Accuracy: Repeatability: ± 2% of full scale

± 2% of full scale

Zero drift at constant temp: not specified

Zero drift temp effect: Operating temp range: not specified

5-40 °C

Storage temp:

not specified

Weight:

15 kg

Dims:

23x20x45 cm.

Output signal:

0-1Vdc

Calibration:

not specified

Cal controls:

not specified

TEST RESULTS: none

COMMENTS: no battery option.

Siemens Industrial Automation, Inc.

Distributor:

100 Technology Dr.

Flow Tech

Alpharetta, GA 30202

Hunt Valley, MD

(404)740-3932 Fax (404)3998

Model:

ULTRAMAT 21/O₂

Price:

\$4600.00

Method: Ranges:

NDIR 0-10%

Power:

120Vac only

Sampling Pump:

Internal

Alarms:

2 per channel

Display:

digital

Accuracy: Repeatability: ± 1% of reading \pm 1% of reading

Zero drift at constant temp: 0.2% of range per week

Zero drift temp effect:

not specified

Operating temp range:

not specified

Storage temp:

not specified 20 lb (9 kg)

Weight: Dims:

17.2x6.6x11.4 in. (44x17x29 cm)

Output signal:

analog 0-20ma

Calibration:

zero/daily; span/yearly

Cal controls:

zero/span

TEST RESULTS: A 21/02 analyzer with 0-20% CO2, 0-25% O₂ and 0-20 ppm CO ranges was tested 10/4 to 10/6 '94. A 20% CO₂ cal gas would be needed to set/check the span and none was available, so the unit was tested using its as received span setting. The unit was evaluated with a 5% CO₂ gas using the STEC gas divider to make dilutions. The test results were excellent. The unit was tested with 10 ppm CO/2540 ppm CO₂ and gave excellent results. Short term repeatability was exact over the 0-5% range.

COMMENTS: The unit must be autocaled daily with zero gas for good low level accuracy and again whenever the environmental conditions change. The unit, with 3 analyzers, is very heavy. It must be operated in the horizontal, on a flat surface. A short 2 in. drop test showed zero deflection of the display.

Telaire Systems, Inc.

6489 Calle Real

Goleta, CA 93117

(800)472-6075 (805)964-1699

(003)304-1033 East (005)064-2124 Distributor:

Jo Mitchel

P J Envirolytics

Hamburg, N.J.

(201)209-1444

Fax (805)964-2129

Model:

1050 CO₂ Monitor

Price:

\$500.00

Method:

NDIR

Ranges:

0-1999 PPM

Power:

Battery with 115Vac recharger operation

Sampling Pump:

none/diffusion

Alarms:

user set single point alarm

Display:

digital

Accuracy:

± 50 ppm

Repeatability:

± 20 ppm

Zero drift at constant temp:

100 ppm/year

Zero drift temp effect:

not specified

Pressure dependence:

+0.19% reading per mm Hg.

Operating temp range:

32-122 °F (0-50 °C)

Storage temp:

140 to 140 °C (-40 to 60 °C)

Weight:

22 oz. (624 gm)

Dims:

7.5x3.8x3 in. (19x9.7x7.6 cm)

Output signal:

0-2Vdc @ 0-1999 PPM (2-4Vdc @ 2000-5000 PPM)

Calibration:

? yearly ??

Cal controls:

zero/span

TEST RESULTS: none

<u>COMMENTS</u>: This unit does not cover desired range, but has a very attractive price. The vendor will not supply loaners nor help in finding a local user (they are not computerized to search a user file).

Teledyne Brown Engineering, Inc.

Analytical Instruments

16830 Chestnut St.

Box 1580

City of Industry, CA 91749-1580

(818)961-9221

Fax (818)961-2538

Model:

730 Series

Price:

\$3450.00 and up

Method:

NDIR

Ranges:

0-10% and others

Power:

115Vac, can supply a 24Vdc power version

Sampling Pump:

Alarms:

none/?

Display:

digital

Accuracy:

± 2% F.S.

Repeatability:

± 1% F.S.

Zero drift at constant temp: 1% F.S./week

Zero drift temp effect:

Operating temp range:

5 to 45 °C(41-113 °F)

Storage temp:

Weight:

20 lb

Dims:

models vary

Output signal:

4-20mAdc, 0-1Vdc

Calibration:

daily/?

Cal controls:

TEST RESULTS: none

COMMENTS: This sensor is used in the Hamilton Standard space backpack to replace the old Beckman sensor.

COMPANIES CONTACTED BUT ANALYZERS REJECTED

The companies listed below were contacted for the CO₂ analyzer survey, but their units were rejected for various reasons.

1. AIM USA

P.O. Box 720540 Houston, TX 77272-0540 (800)274-4246 Hand held but do not do CO₂.

2. Bachrach, Inc.

625 Alpha Dr. Pittsburgh, PA 15238-2878 (412)963-2157

Their units are for stack gas monitoring primarily.

3. Biosystems, Inc.

5 Brookside Dr.
Middlefield, CT 06455
(203)344-1079
Their units do not do CC

Their units do not do CO₂.

4. Bruel & Kjaer

185 Forest St.

Marlborough, MA 01752

(508)-481-7000

An in-house demonstration of the B & K Model 1302 analyzer was a complete failure. No consideration was given to this unit following the demo.

5. Columbus Instruments

Columbus, OH

(614)488-6176

Their "Ferm-180" is 115VAC, high accuracy/high sensitivity unit for 0-15% $CO_2/0-20\%$ O_2 . No portable units.

6. COSMOS/Sam Dick Industries, Inc.

1140 N.W. 46th St.

Seattle, WA 98107

(206)789-5410

Fax (206)7895414

An interesting device that uses a sensitive thermal conductivity detector to measure the composition of one gas in another. It is non-specific so of no use in this study but may be a simple easy-to-use item to replace a total hydrocarbon analyzer.

7. Enviro Systems Ltd.

Electron House

Higher Hilgate Stockport

Cheshire SKI 3QD England

44(0)61 474 7477

They make a unit which can measure NH3, formaldehyde, etc. of unspecified methodology. It is not applicable to this program, but might apply to a program to quantitate special species not generally found by the normal test procedures.

8. Foxboro Co.

P.O. Box 500

East Bridgewater, Ma 02333

(508)-378-5556

These units are too large and do not cover the 7.5% range.

9. GAC/General Analysis Corp

140 Water St.

South Norwalk CT 06854

(203)-852-8999

They do not have a portable unit and do not want to make one. Their fixed unit was too large to be moved easily.

10. Gasalarm Systems Corp.

Houston, Texas

(713)-364-1988

They do not have an off the shelf fixed or portable unit for this application.

11. HNU Systems, Inc.

160 Charlemont St.

Newton, MA 02161-9987

(800)724-5600

They make PID's & portable GC's, not germane to this study.

12. IMR/Environmental Equipment, Inc.

5401 Central Ave.

St. Petersburg, FL 33710

(813)328-2818

A nice looking stack gas analyzer of no interest.

13. MDA Scientific, Inc.

Evanston, ILL

(800)344-4632

They do not make any CO₂ analyzers.

14. MTI/Microsensor Tech. Corp.

41762 Christy St.

Fremont, CA 94538

(510)-490-0900

Portable GC for fixed gas analysis. Too \$ and complicated.

15. Neotronics

2144 Hilton Dr. SW

Gainsville, GA 30501-6153

(800)-535-0606

This company did not reply to a request for information.

16. Penn-Del Inst. Sales Inc.

709 Bethlehem Pike

Philadelphia, PA 19118

(215)-836-9100

Tested Horiba Model APBA-210 in house. Unit does not cover the 7.5% range and showed poor performance and poor zero stability.

17. Photovac, Inc.

25-B Jefryn Blvd. West

Deer Park, NY 11729

(516)254-4199

These units are portable hand held gas chromatographs that are too complicated for the specified use.

18. Rosemount Analytical Inc.

600 South Harbor Blvd.

Le Habre, CA 90631

(213)-690-7600

No portables. No movable fixed units.

19. Sierra Monitor, Inc.

1991 Tarob Ct.

Milpitas, CA 95035

(408)262-6611

No portable units; remote sensors & controllers only.

20. Teledyne Analytical Instruments, Inc.

Pasadena, CA

(818)961-9221

Most of their units are combustion analyzers that do not measure CO₂ directly, but calculate it from a combustion equation. Not applicable to this study. Their "Mini-IR" sensor does apply.

- Thermal Environmental Inst. Inc.
 West Forge Pkwy.
 Franklin, MA 02038
 (508)-520-1460
 Low range, large, expensive, fixed units only.
- Universal Sensors, Inc.
 5258 Veterans Blvd.
 Mt. Airie, LA 70006
 (504)885-8443
 They do not make a portable CO₂ analyzer.

APPENDIX B: FIELD TESTING PROTOCOL.

FIELD TESTING INFO FOR SUBMARINE PORTABLE CO₂ ANALYZER

NMRI POC: Dr. Richard Lillo

Naval Medical Research Institute

Code 541

8901 Wisconsin Ave.

Bethesda, MD 20889-5607

(301) 295-5883/-5882

DSN 295-5883/-5882

1. Background

NMRI was tasked by NSMRL to identify a portable CO_2 analyzer for use on U.S. Navy submarines. This task involved a market search, instrument testing in the laboratory, and now field testing of the candidate analyzer, the <u>Geotechnical Infra-red Analyzer</u>. This analyzer measures CO_2 up to 7.5%.

2. Your job

Your job is to help us by performing the field test which will be done on at least one U.S. sub. Results from your testing will help to evaluate:

- a. how "sailor friendly" the analyzer is
- b. stability of instrument under actual sub conditions
- c. potential problems with draft procedures
- d. comparison of analyzer and CAMS-I CO₂ measurements

3. Equipment

- a. 1 Geotechnical CO₂ analyzer for <u>1 ATA</u> use
- b. Battery charger for analyzer
- c. Sampling tubing
- d. Data sheets

4. Test Plan

- a. Check calibration (do not recalibrate) once a day prior to use.
- b. Following calibration check, take CO₂ measurements throughout the sub spaces.
- c. Record (when possible) simultaneous CAMS-I readings for spaces where portable ${\rm CO_2}$ analyzer is used.


Instrument procedures

Batteries/charging.

The CO₂ analyzer is normally run off its self-contained NiCad batteries. However, when the batteries require charging, the analyzer can be used when it is attached to the charger. The charger plugs into 110 volt line current. The instrument must have batteries in place to operate. Ideally, NiCad batteries should be fully discharged and recharged during operation rather than continually topped off without a full discharge. However, this probably will not be possible - don't worry. An overnight charging should provide 12 h of usage.

Calibration check.

- 1. Instrument has been calibrated at NMRI. Do not recalibrate.
- 2. Locate the CAMS-I calibration gas and install on its regulator the tubing we have supplied. This tubing contains a tee to allow sampling with the analyzer. Connect the inlet port of the CO_2 analyzer to the side branch of tubing so that calibration gas can be sampled without pressurizing the analyzer.



- 3. Purge the CAMS-I regulator 3 times to insure removal of all ambient air from the regulator; then dial in a delivery pressure of several psig. Leave gas cylinder turned on but secure flow using the regulator outflow valve.
- 4. Turn on analyzer by pressing the red key. The LCD will show the company name, model no., and information on key functions.
- 5. Press the "0" key to exit that screen. The LCD display will show the following choices:
 - 1-General Utilities
 - 2-Read Gas Levels
 - 3-View/Print/Analyze
 - 4-Download Data
- 6. Press "1" for General Utilities. The display will show the following:
 - 1-Check Time/Date
 - 2-Battery Status
 - 3-Memory
 - 4-Calibration 0-Exit
- 7. Press "2" to read the available battery capacity. If there is insufficient charge, attach analyzer to charger that is run off 110 volt line current and a) charge for at least 1 hour or b) use while charging.
- 8. Press "0" twice and then "2" to read gas level. Press "5" to turn on pump. Analyzer is now measuring CO_2 . Allow to warm up for 5 min.
- 9. Open the CAMS-I regulator valve and adjust gas flow so it is just audible as it exits the tubing.
- 10. Wait at least 1 min for reading to stabilize. Record reading at top of daily data sheet.
- 11. Shut off calibration gas flow.
- 12. Close valve on CAMS-I cylinder and bleed regulator down.
- 13. Leave analyzer on. Analyzer can now be moved about the sub to measure CO₂.
- 14. For each reading, use a separate line on the data sheet. Include any comments on the bottom.
- 15. When finished turn analyzer off by pressing red key.

16. Subsequent sampling for CO_2 during the same day can be done without repeating calibration check. Simply turn on the instrument by pressing the red key, press "0", then "2", then "5"; allow to warm up 5 min before using.

NMRI

CO2 Sampling Data Sheet (Use New Sheet Each Day)

| CO2 Unit: | Geotech CD500LB | Date: | | | | |
|-----------|-------------------------------|-----------------------------|--------------------|-------------------|--------------------|--|
| Time On: | | Submarir | Submarine: | | | |
| | | Operator: | | | | |
| CO2 Conc | centration in CAMS Gas: | | | | | |
| Geotech C | CAMS Gas Reading: (DO FIRST I | (%) EACH DAY) | Time Chec | :ked: | | |
| Time | Location | CAMS-1 Reading (Torr) | Pressure (Torr) | CAMS-1 CO2 (%) | Geotech CO2 (%) | |
| | Torpedo Room | | | | | |
| | Crew's Mess | | | | | |
| | Battery Exhaust | | | | | |
| | Fan Room | <u> </u> | | | | |
| | Missile Room | | | | | |
| | R-12 Plant | | | | | |
| | Tunnel | | | | | |
| | CO2 Scrubber | | | | | |
| | AMR2 | | | | | |
| | R-114 | | | | | |
| | Engine Room | | | | | |
| | <u>-</u> | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| Notes: | | | | | | |
| | | | | | | |
| | | | | | | |
| Í | | | | | | |

APPENDIX C: OPERATING PROCEDURES FOR THE RECOMMENDED ANALYZER, GEOTECHNICAL CDM-1000/LONG.

Sufficient information is provided here to calibrate and measure CO₂ onboard a submarine. It is assumed that the calibration gases will not be onboard and that the user will have calibrated the unit prior to going onto the submarine. This was the rationale behind the 90-day testing during which the instrument was not recalibrated. Other instrument functions are available which can be accessed via the menu but won't be discussed here.

Batteries/charging

The CO₂ analyzer is normally run off its self-contained NiCad batteries. However, when the batteries require charging, the analyzer can be used when it is attached to the charger. The charger plugs into 110 volt line current. The instrument must have batteries in place to operate. Ideally, NiCad batteries should be fully discharged and recharged during operation rather than continually topped off without a full discharge. However, this probably will not be possible. An overnight charging should provide 12 h of usage.

Calibration and Use

- 1. Calibration should be done at temperatures 18 to 24 °C (65 to 75 °F).
- 2. Required gases with high-purity (stainless steel diaphragm) regulators to allow adjustment of gas flow down to several liters/min:
 - a. Zero gas = CO_2 -free, hydrocarbon-free air
- b. Span gas = 7.5% CO₂, balance hydrocarbon-free air, primary standard certified to \pm 1% relative.
- 3. Purge both regulators 3 times to insure removal of all ambient air from the regulator; then dial in a delivery pressure of several psig. Leave gas cylinder turned on but secure flow using the regulator outflow valve.
- 4. On both regulators, install tubing (e.g., Tygon, nylon, Teflon) that contains a tee to allow sampling with the analyzer.
- 5. Turn on analyzer by pressing the red key. The LCD will show the company name, model no., and information on key functions.

- 6. Press the "0" key to exit that screen. The LCD display will show the following choices:
 - 1-General Utilities
 - 2-Read Gas Levels
 - 3-View/Print/Analyze
 - 4-Download Data
- 7. Press "1" for General Utilities. The display will show the following:
 - 1-Check Time/Date
 - 2-Battery Status
 - 3-Memory
 - 4-Calibration 0-Exit
- 8. Press "2" to read the available battery capacity. If there is insufficient charge, attach analyzer to charger that is run off 110 volt line current and a) charge for at least 1 hour or b) use while charging.
- 9. Press "0" to return to the previous screen. Press the "4" key to calibrate. Press "5" to start pump. Allow to warm up for 5 min.
- 10. Connect the inlet port of the CO₂ analyzer to the side branch of the Span gas tubing so that calibration gas can be sampled without pressurizing the analyzer (in similar fashion as with NMRI testing in Fig. 1 of this report).
- 11. Open the Span gas regulator valve and adjust gas flow so it is just audible as it exits the tubing.
- 12. Wait at least 1 min for reading to stabilize. If reading is <u>within 0.20%</u> of the calibration gas (e.g., $7.50 \pm 0.20\%$), <u>calibration is unnecessary</u>, shut off calibration gas flow, and go to step #17.
- 13. If <u>calibration is necessary</u>, press "1" to calibrate and then enter CO_2 concentration (e.g., 7.50%). To backspace over an entry mistake, press and hold "0".
- 14. Press "0" to exit screen and then "1" (i.e., "Yes") to calibrate.
- 15. Observe readout. Meter reading should be within 0.20% of the calibration value. Calibration can be repeated if desired.
- 16. Shut off Span gas flow.
- 17. Press "0" twice and then "2" to read gas level. Press "5" to turn on pump. Analyzer is now measuring CO_2 .

- 18. Remove span gas tubing and attach Zero gas tubing to analyzer.
- 19. Open the Zero gas regulator valve and adjust gas flow so it is just audible as it exits the tubing.
- 20. Wait at least 1 min for reading to stabilize. If reading is not within 0.20% of 0, instrument should not be used unless this problem is corrected.
- 21. Shut off Zero gas flow, close valves on both gas cylinders, and bleed down regulators.
- 22. Turn analyzer off by pressing the red key and remove Zero gas tubing. Instrument is now calibrated and NMRI testing indicates analyzer should be useable for up to 90 days without recalibration with estimated accuracy \pm 25% relative.
- 23. Analyzer can now be moved onto the submarine to measure CO_2 . Simply turn on the instrument by pressing the red key, press "0", then "2", then "5"; allow to warm up 5 min before using.